




JLS38 (18GA. 1/4" NARROW CROWN STAPLER)

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	BOLT (M5x12L)	Z-05-120	1	29	END CAP	JNS45-B-002	1	57	CLICK LEVER PIN	F30-L-003	1
2	EXHAUST COVER WASHER	T64-C-004	1	30	PLUG CAP	9032-B-006	1	58	STAPLE GUIDE SUPPORT	JLS38-M-008	1
3	EXHAUST COVER	T64-C-003	1	31	AIR PLUG	9032-B-005	1	59	PIN STOPPER O-RING	CT64-M-008	1
4	BOLT (M5x25L)	Z-05-250	4	32	BOLT (M5x30L)	ZN-05-300	2	60	CLICK LEVER SPRING	JLS38-L-004	1
5	SPRING WASHER (for M5)	W-05	6	33	DRIVER GUIDE	JLS38-G-001	1	61	CLICK LEVER	JLS38-L-002	1
6	CAP	T50-C-001	1	34	SPACER	JLS38-G-002	1	62	RETAINER	JLS38-M-012	1
7	GASKET	T64-C-002	1	35	NOZZLE	JLS38-B-007	1	63	MAGAZINE STOPPER	JLS38-M-011	1
8	PISTON STOPPER	T64-H-005	1	36	BOLT (M4x6L)	Z-04-060	2	64	BOLT (M4x10L)	Z-04-100	1
9	HEAD VALVE SPRING	T64-H-006	1	37	SAFETY GUIDE COVER	JLS38-S-010	1	65	SPRING WASHER (for M4)	W-04	2
10	HEAD VALVE O-RING (IN)	T64-H-003	1	38	BOLT (M4x18L)	ZN-04-180	2	66	BOLT (M4x12L)	ZN-04-120	1
11	HEAD VALVE	T64-H-001	1	39	CONTACT ARM	JLS38-S-001	1	67	BRACKET	JLS38-M-006	1
12	HEAD VALVE O-RING (OUT)	T64-H-004	1	40	NO MAR PAD	JLS38-S-011	1	68	BOLT (M5x14L)	Z-05-140	1
13	HEAD VALVE SEAL	T64-H-002	1	41	RETAINER	T64-S-006	1	69	LOCK NUT (for M5)	NN-05	1
14	COLLAR	T64-A-004	1	42	CONNECTOR	T64-S-002	1	70	VALVE SET	NV-V-P001	1
15	PISTON SET	JLS38P-P001	1	43	CONNECTOR HOUSING	T64-S-003	1	71	VALVE O-RING	NV-V-001	1
16	PISTON O-RING	1651S-P-003	1	44	CONNECTOR HOLDER	T64-S-005	1	72	PLUNGER CAP O-RING	CT64-V-011	1
17	PISTON ASSEMBLY	JLS38-P-P002	1	45	CONNECTOR SPRING	T64-S-004	1	73	VALVE	NV-V-003	1
18	CYLINDER	T50-A-001	1	46	TRIGGER A (OUT)	JN45R-T-001	1	74	PIN (Φ3x14.2L)	NV-V-013	2
19	CYLINDER O-RING	1665-A-005	1	47	TRIGGER B (IN)	JN45R-T-002	1	75	VALVE PLUNGER O-RING (UP)	NV-V-004	1
20	CYLINDER GUIDE	T64-A-002	1	48	ROLL PIN (Φ2.5x16L)	R-25-160	1	76	VALVE PLUNGER	NV-V-007	1
21	CYLINDER GUIDE O-RING	JPS38R-A-006	1	49	PUSHER	JLS38-M-003	1	77	VALVE PLUNGER O-RING (MID)	CT64-V-005	1
22	SUPPLY HOLE SEAL	1651-A-007	1	50	MAGAZINE A	JLS38-M-001	1	78	VALVE PLUNGER O-RING (LOW)	NV-V-006	1
23	BUMPER	T64-A-003	1	51	MAGAZINE B SET	JLS38-M-P001	1	79	PLUNGER O-RING	CT64-V-008	2
24	ROLL PIN (Φ3x28L)	R-30-280	2	52	PUSHER SPRING	422-M-004	2	80	PLUNGER SPRING	CT64-V-009	1
25	ROLL PIN (Φ3x22L)	R-30-220	1	53	PUSHER GUIDE	JLS38-M-013	2	81	PLUNGER	NV-V-010	1
26	BODY	T64-B-001	1	54	MAGAZINE END CAP	JLS38-L-001	1	82	PLUNGER CAP	NV-V-012	1
27	GRIP	JN2190-B-004	1	55	BUSHING	F30-L-007	2				
28	END CAP O-RING	JNS45-B-003	1	56	BOLT (M4x10L)	ZN-04-100	2				

*** All the parts of stapler can be changed for improvement and re-design without announcement.

(REV. : 2013/06/20)