

Cocoon Z High Chair | Lounger Cleaning Guide



Daily cleaning



- ✓ Simply wipe and disinfect the tray. Handwash or use dishwasher.
- ✓ Wipe down EVA seat with damp cloth. Spot clean with a bit of soap if necessary.

* Do not spray water or cleaning liquid.

Weekly extra cleaning



- ✓ Remove the EVA seat pad and harness. Soak in soap water and rub off any stubborn stain.
- ✓ Let dry completely before placing back on High Chair.

* Keep all metal parts extra dry!



Monthly deep cleaning



- ✓ Vacuum any crumbs in the crevices.
- ✓ Use a cream-based cleaner to wipe off any stubborn stain.
- ✓ Wipe off any dust under the glider for smooth gliding.

* Never hose down or submerge the chair in water.

IMPORTANT! Always store high chair in a dry, indoor space away from direct sunlight.