

How to connect

Installation takes about 15 minutes.

Disconnect CCFL lamp wire harness from main board

Disconnect Screen wire harness on your old LCD

Remove the old LCD

Mount our Direct Replacement LCD back to the same location

Connect Screen wire harness to our Direct Replacement LCD

Connect other end of the wire adapter to the exist inverter wire harness

Our Direct Replacement LCD has the same interface connector, dimension and screw hole as the old LCD.

Our Direct Replacement LCD included the following items:

- 1) LCD screen (it has upgraded to Sunlight Readable LED kit)
- 1) LED driver
- 1) Wire adapter

Looking for technical assistance?

We love to help!

Please visit us online at

[http://store.lcdparts.net/tech-support ep 45.html](http://store.lcdparts.net/tech-support_ep_45.html)