MoniServ, Inc.| <u>http://lcdpart.com</u> | techsupport@lcdparts.net 1600 Noriega Street | San Francisco | CA 94122 | 1-415-682-8685

## How to connect

Installation takes about 15 minutes.

Disconnect CCFL lamp wire harness from main board

Disconnect Screen wire harness on your old LCD

Remove the old LCD

Mount our Direct Replacement LCD back to the same location

Connect Screen wire harness to our Direct Replacement LCD

Solder Red wire to Pin 1 as shown on photo (Or can be connected it directly to power supply Input positive terminal)

Solder Black wire Pin 2 as shown on photo (Or can be connected it directly to power supply Input negative terminal)

Our Direct Replacement LCD has the same interface connector, dimension and screw hole as the old LCD.

Our Direct Replacement LCD included the following items:


- 1) LCD screen (it has upgraded to Sunlight Readable LED kit)
- 1) MS610UB LED driver
- 1) A Wire connector

## Looking for technical assistance?

We love to help!

## Please visit us online at

http://store.lcdparts.net/tech-support\_ep\_45.html



MoniServ, Inc. | <u>http://lcdpart.com</u> | techsupport@lcdparts.net 1600 Noriega Street | San Francisco | CA 94122 | 1-415-682-8685