
KIN@rinder







The Interior Adjustment of K0, K1, K2, K3, K5 manual coffee grinder KINGrinder Manual - Interior Adjustment

How to operate the grinder?

- 1. Rotate anti-clockwise to the desired grind setting from zero.
- 2. Take out the handle and the PC lid, load 20~25g of coffee beans into it.
- 3. Put on the **handle** and the **PC lid** then spin the **handle** clockwise till it has done.

How to install the PC lid? (There are method A and method B)

- A. Default setting: the **PC lid** and the **handle** are separate-able for grinding (drill-grinding is applicable).
- B. Attach the **PC lid** and the **handle**: Take out the **Black O-ring** Place the **White O-ring** into the groove.

How to adjust grind setting?

- 1. Take out the **receiver**. Hold the **handle** to prevent rotation.
- 2. Rotate the **spin dial** clockwise till tightened. The corresponding number is zero and the number on the **numerical dial** may not be the same as the number of clicks from the grind setting.
- 3. Rotate the **spin dial** anti-clockwise from the zero to your grind size.
- 4. Rotate the **spin dial** anti-clockwise for a coarser grind and vice versa.

KIN@rinder	KO	K1	K2	K3	K5
Extra Fine	×	28~35		28~40	
Fine	×	35~60		40~60	
Medium-Fine	60~80				
Medium	80~100			80~120	80~100
Coarse	140				

How to disassembling the grinder?

1. Take out the receiver. Rotate the spin dial anti-clockwise for dismantling the

grinder.

2. Take out the components in order. The **spin dial**, the **numerical dial**, the

inner burr, the spring and the bearing cover.

How to assembling the grinder?

1. Put on the components in order. The **bearing cover** and the **spring**. There

are two shapes of the **bearing cover**: flat design and curve design. The

curve design shape of the bearing cover facing upward.

2. Attach the inner burr and the numerical dial to the rectangle shape of the

central shaft to proceed with assembling the grinder.

3. Install the **spin dial** and rotate clockwise to complete the assembly.

What's to do and not to do?

Cleansing with a brush.

• Don't wash the grinder with water.

• Don't disassemble the central shaft and the burr ring unit.

@: hello@kingrinder.com

Website: www.kingrinder.com

Instagram: KINGrinder

Linktree: KINGrinder

