

THUNDERSTRUCK 700




User Manual

SPECIFICATIONS

Bluetooth version:	Bluetooth V5.0		
Effective transmission range:	10 m		
Battery:	300mAh Li polymer battery		
Charging time:	2.5 hours (maximum)		
Playing time:	10 hours		
Stand-by time:	up to 30 days		
LED indicator status:	Blue LED for power and BT pairing indicator; Red LED for charging indicato		
Diameter of driver unit:	40mm		
Frequency range:	20Hz~20kHz		
Sensitivity at 1KHz:	100+/-5 dB		
Impedance:	32+/-15% Ω		
Distortion:	≤1% at 1KHz		
Rated poweroutput:	10mW		
Net Weight:	Approx. 156g		

ACCESSORIES

Micro USB charging cable	
3.5mm audio cable	
Instruction manual	



0	Volume Up / Track Back		Increase the volume Go to next song
0	Multifunction button	b 1	On/Off Play Pause Call/Answer/Hang Up
0	Volume Down / Track Forward		Decrease the volume Go to previous song
•	82 B F		Mara USO at

3.5mm audio plug

Micro USB charging port

LED indicator

Microphone

CHARGING THE HEADPHONES

Use the Micro USB Cable and connect the headphone to your computer or adaptor device which is compatible with USB charging. A red LED indicator will turn on to indicate that the headphone is getting charged. As soon as the headphone is fully charged, the red LED light will turn off.

PAIRING

- Make sure your phone, computer or music device is turned on and within 1 meter of the headphone.
- Press the multifunction On/Off button (2) for about 3 seconds until the LED light starts to flash BLUE and RED quickly.
- Activate the Bluetooth feature on your phone or device and set it to search for Bluetooth devices (discoverable).
- Select "THUNDERSTRUCK 700" from the list of found devices.
 If necessary, enter passcode "0000" to pair and connect the headphone to your device.
- Once successfully paired, the LED light will flash BLUE once every few seconds.

PLAYBACK / CONTROLS

- Press Multifunction button Play/Pause (2) to start and pause audio
- Press (button 1) to skip forward to next track. Press and hold down button to increase volume.
- § Press (button 3) to go back to previous track. Press and hold down button to decrease volume.

Note: The controls will not function when the headphone is being charged.

3

CALLS

- To answer an incoming call, press the Multifunction button (2).
- 2 To end call, press the same button again
- To decrease or increase the volume during the call, press and hold down button 3 or button 1

POWER ON

Press and hold the Multifunction button (2) to turn the headphones on. The LED light will flash BLUE when headphones are on.


POWER OFF

Press and hold the Multifunction button (2) to turn the headphones off. The LED light will stop flashing when off.

Using headphones in Passive Mode (Wired)

You can use the headphones as a wired headphone to save battery. Simply connect one end of the 3.5mm cable to the bottom of the ear cushion and the other end to your phone or device.

Note: Inserting an audio cable disables wireless functionality.



Removable Earcups

- You can then hand wash the ear pads with soap. Please do not use bleach.
- Leave the ear pads to air dry, do not tumble dry. When the airpads have dried, re-insert the plastic backing making sure it is the right way up according to the arrow and it is the correct side (left/right)
- S Now, simply clip the ear pad back onto the headband, making sure you are connecting it to the correct side (left/right). Make sure that all 4 clips have snapped together, there should be no gaps around the edge.

Caution: Please be careful while removing and attaching the earpads in order to avoid the clip connecting portions from getting damaged.



Important Safety Information

Listen Responsibly

To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headphones.

After placing headphones in/on your ears, gradually turn up the volume until you reach a comfortable listening level. Noise levels are measured in decibels (dB), exposure to any noise at or above 85 dB can cause gradual hearing loss. Monitor your use; hearing loss is a function of loudness versus time. The louder it is, the less time you can be exposed to it. The softer it is, the more time you can listen to it.

Use Responsibly

Do not use headphones when it's unsafe to do so—while operating a vehicle, crossing streets, or during any activity or in an environment where your full attention to your surroundings is required.

It's dangerous to drive while wearing headphones, and in many places, illegal because it decreases your chances of hearing life-saving sounds outside of your vehicle, such as another car's horn and emergency vehicle sirens. Please avoid wearing your headphones while driving.

Thanks for purchasing THUNDERSTRUCK 700. Please read the instructions carefully before using it to know the functionalities of the product.

If at any time in the future you need to dispose of this product, please note that you should not dispose electronic products with household waste. Please recycle where there are facilities available and check with your local authorities or retailers for recycling advise.

MULO TECHNOLOGIES LLP E-3, Calcutta Greens Commercial Complex Kolkata – 700075 033-2416-2244



Model: THUNDERSTRUCK 700

N

5

7