


General Functions

Answer/End a call 🧈

When there's an incoming call, press the Power button to answer.After receiving the call, if you want to end the call, press the Power button again.




Reject a call 🌈

When there's an incoming call, long press Power button for 1 second.



Redial last number **C** To redial last number, double press the Power button.



Tips

1. Before using the earphone, please read the user manual carefully and keep it for future reference.

- 2. The earphones require a full charge prior to first-time use.
- 3. If the earphones are left unused for over two weeks, please recharge before use.
- 4. Use only certified chargers to charge the neckband.
- 5. If the earphones are undiscoverable, please check whether they are in pairing mode. If left in pairing mode for a long time, they will exit pairing mode. Please re-enter the mode; if a procedure error of your phone occurs, reboot it. If a procedure error of the earphone occurs, reboot or reset it.
- 1. Never disassemble or modify your earphones for any reasons to avoid any damages and danger.
- Do not use these earphones during a thunderstorm to avoid irregular function and increased risk of electric shock.
- 3. Do not use harsh chemicals or strong detergents to clean the earphones.
- 4. Keep the earphones dry.

13