X Performance

## X9ERGOKEY

ERGONOMIC KEYBOARD WITH PALM REST FOR PC
User's Guide

www.x9performance.com

Introduction

The X9 Performance X9ERGOKEY is a split ergonomic USB wired keyboard, especially designed for PC. It has 110 full size keycaps for a sensitive and responsive touch. It also has 17 convenient preset shortcut keys for one-touch control of PC applications and a 17-key numeric keypad to quickly and efficiently enter long sequences of numbers.

The split ergonomic design of the X9ERGOKEY encourages natural hand, wrist and forearm positions. A cushioned palm rest provides support and promotes a neutral wrist position.

The stylish X9 Performance X9ERGOKEY is a perfect match for your PC computer as it will greatly help you to increase your productivity while boosting your comfort level!

Package Contents

· Keyboard
· User's guide

Tech Support

Please E-mail us at techsupport@x9performance.com, or call us at 1-909-230-6888 Monday to Friday, 8:30AM to 5:30PM, Pacific Standard Time

1

X9 Performance Product Information

Warranty

X9 Performance warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year from the date of purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, X9 Performance will repair or replace the product. This warranty shall not apply to products that have been subject to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered as normal use.

Limitation of Liability

The liability of X9 Performance arising from this warranty and sale shall be limited to a refund of the purchase price. In no event shall X9 Performance be liable for costs of procurement of substitute products or services, or for any lost profit, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply not with standing any failure of essential purpose of any limited remedy.

Copyright® 2020 by X9 Performance

System Requirement

· Windows 7/8/10 or later; Chromebook and Chrome OS
· Any desktop and notebook computer with a USB-A port available

2

Hardware Basics

Function keys mode F1 to F12

When Fn Lock LED is on, F1 to F12 function keys are the default when top row keys are pressed. Also 12 blue colored shortcut keys require pressing fn key simultaneously to work. You can toggle between Function key mode and shortcut mode by pressing fn and Esc keys simultaneously, Fn Lock LED is on to indicate it is in Function key mode, otherwise it is in shortcut mode.

3

Installation Instruction

The X9ERGOKEY is automatically recognized by the computer and does not require a driver. Simply plug the keyboard directly into a USB port in your computer and you are ready to go!

Shortcut Keys

Below are the description of all 17 shortcut keys. 12 blue colored shortcut keys require (1) pressing fn key simultaneously to work when Fn Lock LED is on, or (2) pressing top row key itself to work when Fn Lock LED is turned off by pressing fn and Esc keys together. Pressing fn and Esc keys toggles between Function key mode and shortcut mode of the keyboard.

Default web browser	Next Track
Open email program	Mute
Open Windows File Explorer	Volume Down
Open Windows search	Volume Up
Print	Open Calculator
File save	Brightness change to PC built-in display
Default music player	
Previous Track	Lock Windows PC
Play/Pause	Open System setting (working under Function key mode)

4