


D8-MST2015L/H Connections



(XM) SiriusXM Adapter Cable: For use only when installing the SiriusXM SXV300 tuner for built-in satellite radio.

(ANT) Bluetooth/WiFi Antenna with extension cable: Thread the copper-colored BT/WiFi Antenna extension cable into the back of the Dynavin. On the other end, thread the BT/WiFi Antenna then run it under the center console near the parking brake for best receptivity. DO NOT position it behind the Dynavin.

(GPS) GPS Antenna: Is magnetic so can be mounted inside the dash on top of anything metal positioned forward in the dash. If reception is not adequate, can be mounted on the inside corner of the windshield or anywhere with good reception. Must be installed in order for the time to display on the Dynavin screen.

(RADIO) AM/FM Radio: Plug in the factory radio tuner plug here.

(CAM) Camera RCA Harness: For use with the factory camera adapter or any aftermarket camera. The brown RCA labeled "CAMERA" is plugged into the brown RCA on the factory camera adapter. Use version "A" or "B" depending on which one fits. If both fit, see which one shows the reverse picture when in reverse and use that one. (The other one will show a blank screen.)

(MIC) Microphone: Must be installed for Bluetooth calling and voice command functionality. Mic can be mounted on the steering wheel column, a pillar, or above the rearview mirror. Test before finishing the installation. (Factory mic is not compatible.)

D8-MST2015L/H Connections

(AUX) Factory Auxiliary Integration: If your car is equipped with an auxiliary plug, you will plug in these RCAs from the MWH (main wire harness).

(MWH) Main Wire Harness: The black end plugs into your car's factory plug.

(USBs) Phone & MDI & CP (or "MEDIA")

Other RCAs: The other red and white RCAs are used with an aftermarket amp only. The red RCA is for an aftermarket sub. The yellow RCA is typically used for a front camera.

The remaining plugs are not currently used.

INCLUDED PARTS



LCD Display Screen



Main Unit/Chassis



Main Wire Harness



Factory Camera Adapter A and Factory Camera Adapter B
(use the one that fits AND works)



GPS Antenna and extension



USB 3' Extension Cables
"Phone" & "Media"



SiriusXM Adapter Cable for
SXV300 Tuner only



Microphone (for BT calling
and voice commands)



Camera RCA Harness (for factory
and aftermarket cameras)



BT/WiFi Antenna



BT/WiFi Antenna Extension



Ribbon cable



Metal mounting brackets



Trim removal tool and fish
tape for running
cables/wires



Cable pulling tool

