


MECHOMOUNT

MACALLY

ECHO DOT WALL SOCKET HOLDER (2nd Gen)

GB User guide



GB USER GUIDE

Tired of shouting commands across the room or staring at that long ugly cord? Then the Macally wall socket Echo mount is perfect for you. With no drilling or screwing required the Echo mount is easy to use and allows you to mount your Echo dot right where you need it.

About this guide

Before you start using the Macally MECHOMOUNT, be sure to read this guide in its entirety.

Safety intructions


Please read the following carefully before using this Macally product. Incorrect use of this product may result in reduced performance, permanent damage and void warranty:

1. Do not place this product near a heat source.
2. Operating temperature of -5°C to 40°C . Storage temperature of -5°C to 40°C .
3. Do not place this product near moisture nor liquids.
4. Operate and store at humidity of 20% to 90% (non-condensing)
5. Do not place heavy objects on this product.
6. Do not drop this product.
7. Do not dispose this product in the garbage. Take it to your local recycling centre.

Package contents


- MECHOMOUNT
- Micro USB cable and User's guide
- *USB power adapter not included

Hardware basics




Installation instructions


1. Insert the rubber adapter gasket into the mount based on the outlet placement.




2. Connect the Micro USB cable to the Echo Dot and Adapter.



3. Place the Echo Dot and adapter into the holder.



4. Connect the MECHOMOUNT into the outlet.



Technical support

Contact us for further technical support! In Europe, Middle East and Africa, please call to +31 24 373 14 10 or email to techsupport@macally-europe.com. Technical support hours in Europe, Middle East and Africa are from 9h00 to 17h00 (CET), from Monday to Friday. In USA, please call to +1 909 230 6888 or email to techsupport@macally.com.

Warranty

Macally Peripherals warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year in North America and (2) years in Europe from the date of the purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, Macally will repair or replace the product. This warranty is exclusive and is limited to the Macally MECHOMOUNT. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered normal use. The liability of Macally Peripherals arising from this warranty and sale shall be limited to a refund of the purchase price. In no event shall Macally Peripherals be liable for costs of procurement of substitute products or services, or for any lost profits, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply notwithstanding any failure of essential purpose of any limited remedy.

Environmental Information for Customers in the European Union



European Directive 2002/96/EC requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

CE Compliance