MACALLY　　　**MINIKEYPROA**

COMPACT USB WIRED KEYBOARD FOR MAC AND PC

User's Guide

www.macally.com

Introduction

The Macally MINIKEYPROA is a stylish compact USB wired keyboard, especially designed for both Mac and PC. It has 78 full size, thin and quiet Scissor-Key-Switch™ keycaps for a sensitive and responsive touch. It also has 13 convenient preset shortcut keys for one-touch control of your Mac and PC applications. The slim MINIKEYPROA is a perfect match for your computer as it will greatly help you to increase your productivity!

Package Contents

• USB Keyboard
• User's guide

Macally Product Information

Technical Support

Please E-mail us at techsupport@macally.com,
In U.S.A. please call 1-909-230-6888
Mon-Fri 8:30 AM - 5:30 PM, Pacific Standard Time

FAQ & help - https://help.macally.com/help

Manual and driver download -
https://us.macally.com/pages/drivers-and-downloads

1

Macally Product Information

Warranty

Macally peripherals warrants that this product will be free from defects in title, materials and manufacturing workmanship for two year from the date of purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, Macally will repair or replace the product. This warranty shall not apply to products that have been subject to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered as normal use.

Limitation of Liability

The liability of Macally Peripherals arising from this warranty and sale shall be limited to a refund of the purchase price. In no event shall Macally Peripherals be liable for costs of procurement of substitute products or services, or for any lost profit, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply not with standing any failure of essential purpose of any limited remedy.

Copyright® 2020 by Macally Peripherals

System Requirement

• Mac OS X 10.3 to 10.15 and above
• Windows 7/8/10 and above
• Any desktop and notebook computer with a USB port available

2

Hardware Basics

Please note: In either Function Lock mode or shortcut mode, del, home, end, pgup and pgdn keys always require holding down fn key together to perform.

Fn LOCK MODE
Function keys F1 to F12

Press "Fn" key with " esc " key simultaneously to switch to Fn Lock mode as default.

3

Shortcut Keys

Shortcut mode - Shortcut mode is the default mode.If Fn and esc keys are pressed together, Fn Lock LED is turned on, keyboard is in Fn Lock mode. You can press Fn and esc keys together again to toggle back to Shortcut mode.

☼☀ Brightness change to built-in display	◀ Mute
⊞ Mission Control (view all open application windows and desktop)	◀)) Volume Down
	◀))) Volume Up
📋 Copy	◀◀ Previous Track
📋 Paste	▶❙❙ Play/Pause
⊛PrtScn Screen capture	▶▶ Next Track
🔒 Power lock icon	⏏ Eject(or on-secreen keyboard on/off switch in iOS/iPadOS device)

In Mac, press 1 second to turn off screen, or press and hold 2-3 seconds to bring up Restart/Shut-down menu.

More about mode

1. Shortcut mode is restored to default mode after MINIKEYPROA loses power, e.g. when unplugged from a computer or a computer is shut down or restarted.
2. In either Shortcut mode or Fn Lock mode, one can also press "Fn" key with one of top row key simultaneously to perform the secondary function without switching mode.

4

## Keyboard Shortcuts for MacOS X and Windows

Previous section has described default shortcuts and function keys. They are supported in the latest MacOS X and Windows OS, no driver installation is needed. Please note, these shortcuts are not universal, certain shortcuts do not work as defined in some application. On the other hand, some shortcuts may act completely different way in different applications. You should try them out first.

Keyboard Setup Assistant in Mac

In Mac, the first time you plug in this new keyboard to use, desktop will pop out a "Keyboard Setup Assistant" window, Please follow the on-screen instruction to identify the keyboard before you can use the keyboard correctly.

After initial setup, if you experience any issue with keyboard or couldn't type correctly, please unplug and replug the keyboard, open keyboard icon in System Preferences, click on "Change Keyboard Type" icon to run Keyboard Setup Assistant to re-identify the keyboard.

5

6

7