


337.0 mm

270.0 mm

MACALLY RFCOMPACTKEY

COMPACT WIRELESS RF KEYBOARD FOR PC

User's Guide



www.macally.com

Introduction

The Macally RFCOMPACTKEY is a 2.4GHz compact wireless RF keyboard with a layout specially designed for PC. This keyboard is ultra slim and compact to save space on the desk and easily store inside a keyboard drawer. The additional shortcut keys further increase efficiency and productivity.

The Macally RFCOMPACTKEY is very easy to use. Simply plug the RF receiver dongle into the USB port of your computer and you are ready to go! Also, no software is required!

Thin, compact, and versatile, the Macally RFCOMPACTKEY is the perfect companion for your PC!

Package Contents

- RFCOMPACTKEY wireless RF keyboard
- USB RF receiver dongle
- 2 "AAA" batteries
- User's guide

Tech Support

Please E-mail us at techsupport@macally.com, or call us at 1-909-230-6888 Monday to Friday, 8:30AM to 5:30PM, Pacific Standard Time

FAQ & help - <https://help.macally.com/help>
Manual and driver download - <https://us.macally.com/pages/drivers-and-downloads>

Macally Product Information

Warranty

Macally peripherals warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year from the date of purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, Macally will repair or replace the product. This warranty shall not apply to products that have been subject to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered as normal use.

Limitation of Liability

The liability of Macally Peripherals arising from this warranty and sale shall be limited to a refund of the purchase price. In no event shall Macally Peripherals be liable for costs of procurement of substitute products or services, or for any lost profit, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply not with standing any failure of essential purpose of any limited remedy.

Copyright© 2019 by Macally Peripherals

System Requirement



- Windows 7/8/10 and later
- Any desktop and notebook computer with a USB-A port available

Hardware Basics



USB RF dongle (plug into a computer USB port)

Caps Lock: green
Battery Low: LED blinks red slow constantly
RF sync period: LED blinks red quickly (3 times per second) for 10 seconds



3

Installation Instructions

The Macally RFCOMPACTKEY is pre-synced with the USB RF receiver dongle, and should be automatically recognized by the computer and does not require a driver. Simply follow the steps below and you are ready to go!

1. Install 2 "AAA" batteries(included) in the battery compartment. Locate the USB RF receiver dongle, in its compartment.
2. Plug the USB RF receiver dongle into the USB port of your computer.
3. Within 5 seconds after step 2, bring the keyboard very close to the receiver dongle and switch to turn on the keyboard power.
4. You are ready to use the RFCOMPACTKEY keyboard.

Shortcut Keys

12 shortcut keys(in blue) on the top of the keyboard provide one-touch control of PC applications and enhanced productivity.

Simply press and hold down Fn key, and simultaneously press the top row key to perform the shortcuts.

Home, End, PgUp and PgDn also require pressing and holding down Fn key to perform.

4

- Open default web browser
- Open mail
- Open default music player
- Previous track
- Play/Pause
- Next track
- Mute
- Volume down
- Volume up
- Insert - Insert
- PrtScn - Print screen
- ScrLk - Scroll lock

5

Front

Peripherals Printing Spec 印刷规格	
Materials Spec: 用料规格:	105G 双铜纸
INKS 颜色油料:	单黑
1 Color Printing 色印刷:	
Additional Process: 额外加工:	6 页翻身折
Note 备注:	