
	300.0 mm			
	MACALLY RKEYA USB WIRED KEYBOARD WITH ROUND KEYCAP FOR MAC User's Guide	Introduction Thank you for purchasing the Macally RKEYA! The Macally RKEY ultra slim USB keyboard with round keycap has a standard layout with 106 full size, yet thin, keys for a comfortable and efficient typing experience. The additional shortcut keys and numeric keypad further increase efficiency and productivity. This keyboard is ultra slim (only 0.7"/18 mm) and compact to save space on the desk and easily store inside a keyboard drawer. The Macally RKEY is very easy to use. Simply plug the cable into the USB port of your Mac computer and you are ready to go! No software is required! The long 5ft/150 cm cable allows you to easily connect your keyboard to your computer, even if it's underneath your desk. Thin, compact and versatile, the Macally RKEY is the perfect companion for your Mac! Before you begin using this product, be sure to read this user's guide in its entirety. • USB Keyboard • USB Keyboard	O mm D mm D main D main <th>USB Plug</th>	USB Plug
	www.macally.com	Macally Product Information Technical Support Please E-mail us at techsupport@macally.com, In U.S.A. please call 1-909-230-6888 Mon-Fri 8:30 AM - 5:30 PM, Pacific Standard Time 1	Mac OS X 10.3 to 10.13 and above Any Apple Mac computer with a USB port available	Function keys F1 to F16 ar Press "Fn" key with " esc " key simultaneously to switch to Fn Lo
180.0 mm – – –	Shortcut Keys Shortcut mode - Shortcut mode is the default mode. If Fn and esc keys are pressed together, Fn Lock LED is turned on, keyboard is in Fn Lock mode. You can press Fn and esc keys together again to toggle back to shortcut mode. ** Brightness change to Mac built-in display • Mute • Mission control • Volume Down • Opy (Cmd-C) • Volume Up • Paste (Cmd-V) • Print (Cmd-P) • Previous Track (Cmd-Left Arrow) • Eject • Next Track (Cmd-Right Arrow) • File save (Cmd-S) • Force Quit Application (Cmd-Dption-Esc) • File save (Cmd-S) • Spotlight Search (Cmd-Spacebar) • File save (Cmd-S)	 More about mode Shortcut mode is restored to default mode after RIKEYA loses power, e.g. when unplugged from a computer or a computer is shut down or restarted. In either Shortcut mode or Fn Lock mode, one can also press "Fn" key with one of top row key simultaneously to perform the secondary function without switching mode. Keyboard Shortcuts for MacOS X Trevious section has described default shortcuts and function keys. They are supported in MacOS X from 10.3 to 10.13 and above, no driver installation is needed. Please note, these shortcuts are not universal, certain shortcuts do not work as defined in some application. On the other hand, some shortcuts may act completely different way in different applications. You should try them out first. Mac, the first time you plug in this new keyboard to use, desktop will pop out a "Keyboard Setup Assistant" window, Please follow the on-screen instruction to identify the keyboard before you can use the keyboard correctly. After initial setup, if you experience any issue with keyboard or couldn't type correctly, please unplug and replug the keyboard, open keyboard icon in System Preferences, click on "Change Keyboard Type" icon to run Keyboard Setup Assistant to re-identify the keyboard. 	Image: Source in the	Keyboard Setup Assista Introduction Your keyboard cannot be identifi identified. To identify this keybo If your keyboard is working prop input device connected to your o can skip this step.
/	4	5	6	

T



7

Front

_ _ _

Peripherals Printing Spec 印刷規格				
Materials Spec: 用料规格:	105G 双铜纸			
INKS 顏色油料: 1 Color Printing 色印刷:	● 単黑			
Additional Process: 额外加工:	🗐 8 页翻身折			
Note 備註:				