


In-Use Screen

After a Massage program is selected, In-use screen displays all settings to that program.



- 1 Time left
- 2 4D intensity level
- 3 Active airbags
- 4 Active rollers
- 5 Bluetooth connected
- 6 Indicators
- 7 Back-roller position & direction

Intelligent Voice Control

To activate the voice control feature on your remote: **Menu > Setting > Voice > On.**

Touch the button on the left speaker, or say "Switch to voice mode" to complete voice control activation.

Use the voice control commands below:
(Once you've activated voice control, give a command within 5 seconds, or you will have to re-activate the voice function.)

- Power On
- Switch Off
- Activate Massage
- Sports Refresh
- Extension
- Rest & Sleep
- Working Relief
- Neck & Shoulder
- Waist & Spine
- Airbag Massage
- Deep Shiatsu
- Healthy Breath
- Massage Extend
- Zero Gravity
- Start Heat
- Heat Off

Share a photo and tag us:

[@infinity_chairs](#)

[@Infinitymassagechairs](#)

[@Infinitymassagechairs](#)

Don't forget to use
#infinitymassagechairs

INFINITY®

72 Stard Road, Seabrook, NH 03874
603-910-5000
www.infinitymassagechairs.com
Version 1.0

INFINITY®

Quick Start Guide

Evolution Max 4D Massage Chair

INFINITY®

Multi-Functional Screen

Use the directional buttons below to navigate these menu screens. Then press OK to select.

Power – Powers up the remote or returns the chair to the exit position and powers down remote.


Home – Shortcut to the home page of all menu screens.

OK – After navigating to the command desired on the display, push OK to select.

Zero Gravity – Press for Zero Gravity 1, press again for Zero Gravity 2, press again to restore recline.

Foot Roller – Press to turn off Foot Reflexology Rollers, press again to resume Foot Reflexology Rollers.

Footrest – Press and hold up arrow to bring foot rest up, press and hold down arrow to bring foot rest down



Pause – Press pause to immediately stop all massage chair activity, press again to resume

Auto – Shortcut to the Auto Programs menu screen

Directional Button – Press up, down, left or right to navigate the display screen

Back Adjustment – Back mechanism position adjustment; press and hold up to raise, press and hold down to lower. Use during initial body scan fine tuning or in manual point or partial zone mode

4D – Press to increase or decrease 4D intensity of back mechanism. In-use screen displays intensity dial

Seat Back Position – Press and hold down arrow to recline the seat back, press and hold the up arrow to upright the seat back

Leg Length – Press and hold right arrow to extend the leg length adjustment, press and hold the left arrow to retract the leg length adjustment