


ACCESSORY DOCK FITTING GUIDE



Mount the Accessory Dock on to the lower section of the handle.

The Accessory Dock does not mount to the metal part of the frame.



Please take note of the direction of the Accessory Dock as this is important.



The PowerBug Accessory Dock allows you to mount up to three trolley accessories to your handle

You can now use an Umbrella Holder, Device Holder and Scorecard Holder simultaneously