

SR-6P SiriusXM Radio Amplified Antenna Installation Instructions

The SR-6P antenna comes packaged with the antenna, a plastic mount, bag of screws, and RG-6 to SMB cable. The mount can be attached to a pole with u bolts or to a wall or other surface with screws. Below is a step by step diagram on how to attached the base to the mount. Be sure to locate the antenna with a clear view of the southern sky when mounting.



← 1. Turn the SR-6P panel face down.

2. Screw the large base into the smaller base and tighten. Be sure not to overtighten.



← 3. Be sure the ball joint is facing up.

3. Both pieces should separate allowing for the base ring to be mounted to a wall or pole. Screw the base ring back on the mount once mounted.

