


ECLIPSE
wearable light clip

BOOKMAN
URBAN
VISIBILITY



MANUAL
ENGLISH

ENGLISH

Eclipse is a rechargeable, wearable light that attaches to clothes and bags with a clip.

Warnings

Do not look directly into the light beam or shine into eyes of others.

Do not submerge under water. Eclipse is water resistant under normal conditions, but not waterproof.

Bookman AB does not accept any liability for injuries or other damages resulting in the use of this product under any circumstances.

Warranty


Eclipse carry a two years warranty from the original purchase date to the original owner (proof of purchase is required). The warranty covers any manufacturing defects in material or workmanship. Issues not covered by warranty include normal wear and tear, improper installation, attempting to access or modify electronics, damage or failure due to accident, misuse, abuse and/or neglect.

Contents

1 × Eclipse


1 × USB/micro USB charging cable

Mounting



1. Open clip by pressing it open
2. Slide it on to garment or bag
3. Release your grip

Operation



On/off: Press and hold 0.7s

Change mode: One click

Operation

MODES	COLOR	POWER	TYPE	RUNTIME
	WHITE LIGHT	HIGH	STEADY —	2 HOURS
	WHITE LIGHT	LOW	STEADY —	12 HOURS
	WHITE LIGHT	LOW	FLASHING ---	40 HOURS
	RED LIGHT	HIGH	STEADY —	2.5 HOURS
	RED LIGHT	HIGH	FLASHING ---	13 HOURS
	RED LIGHT	LOW	FLASHING ---	60 HOURS

Battery indicator

When Eclipse is activated or turned off

More than 20% – 6 times flashing in **green** light.


Less than 20% – 6 times flashing in **yellow** light.

When Eclipse is charging:

If charging – steady **yellow** light

If fully charged – steady **green** light

Charging



1. Open the tab on the back.
2. Connect the micro USB cable.
3. Insert USB plug into powered USB port.

Charge time

2 hours from flat

Battery

Lithium-ion battery

Designed in Sweden

Made in China

Bookman AB, Stockholm, Sweden

www.bookman.se