
Prosport Inc. Digital Boost Gauge


Digital Boost



Wiring Instructions

Red- 12v Accessory Power Yellow-12v Accessory Power Black-Ground green-boost sender (Connects to white wire from sender)

SENSOR MOUNTING: Please mount the sensor inside the cabin. Mounting it in the engine bay will expose it to high temps and possible water/moisture. We take no responsibility in damaged sensors by these elements.



There are a total of 20 PCS of LED lights inside.

and the state of t		
-15~0 PSI	1~ 22 PSI	23~45 PSI
Yellow LED X 6 PCS	Green LED X 7 PCS	Red LED X 7 PCS

- ~ If the boost level is higher then 22 PSI for 3 seconds or more, the digital number will start flashing for warning
- ~ Boost display: Digital type -->-15~45PSI. Analog LED -->-15~45PSI.

