




CPX4 Windlass Spares



Please note that all windlass parts are special order products.
Windlass Parts are Not Returnable!

CPX2-CPX3 Windlass
Exploded View

Optional Gypsy Only Emergency
Manual Recovery Kit



Optional Gypsy/ Drum Emergency
Manual Recovery Kit



Individual parts are included in the following service kits.
(Scroll down to order service kits)

Product Description

Range of spare parts for Lewmar's CPX4 windlass

Part Number	Description	Items Included (Qty)
66000794	Base Kit	15(1), 16(1), 19(1), 20(1) 36(2), 37 (1), 38(2), 41(1)
66000795	Chain Cover Kit	16(1), 38(2)
66000750	Top Nut Kit Gypsy Only	3(1), 17(1)
66000744	Top Nut Kit Gypsy Drum	4(1), 14(1)
66000751	Drum Kit	4(1), 14(1), 22(1)
66000752	Cones & Washer Kit	3(1), 5(1), 6(1), 12(2), 13(1)
66810031	Control Arm Kit	8(1), 10(1), 23(1)
66000796	Mounting Kit	1(4), 18(1), 21(4), 34(4), 35(4)
66000754	Driveshaft Kit Gypsy Only	2(1), 7(1), 11(1), 12(2), 13(1), 39(1), 40(1)
66000755	Driveshaft Kit Gypsy Drum	2(1), 7(1), 9(1), 12(2), 13(1), 39(1), 40(1)
66840003	Gypsy Only Emergency Recovery Kit	24(1)
66840005	Gypsy Drum Emergency Recovery Kit	25(1)
68001063	Gypsy & Stripper Kit (201)	28(1)
68001064	Gypsy & Stripper Kit (202)	29(1)
68001065	Gypsy & Stripper Kit 203)	30(1)
68001066	Gypsy & Stripper Kit (204)	31(1)
68001077	CPX4 12V Motor Gearbox	32(1)
68001078	CPX4 24V Motor Gearbox	33(1)