



E I C H H O L T Z

112396 CONSOLE TABLE CURTIS

ASSEMBLY INSTRUCTION

PARTS

2x

4x




16x

1x

1x

4x

1x



A

B

C


D

E


F

G

1



3



4

