




E I C H H O L T Z

113118 DINING CHAIR VOLANTE

ASSEMBLY INSTRUCTION

PARTS

4x



(A)

4x




(B)

1x



(C)

1



2

