



TL 5.0 SL

USER GUIDE | GUÍA DEL USUARIO | MODE
D'EMPLOI | BENUTZERHANDBUCH | ユーザーガイド

FL 1 STANDARD





FL 1 STANDARD




FL 1 STANDARD




MODES | FUNCIONES | MODI | モード



BATTERY INSTALLATION | INSTALACION DE BATERIA
| INSTALLATION DE LA BATTERIE | EINLEGEN DER
BATTERIEN | バッテリーの取り付け



VISIBLE UP TO 1 MILE | VISIBLE HASTA 1,6 KM |
VISIBLE JUSQU'À 1,6 KM | BIS ZU 1,6 KM SICHTBAR |
1.6キロまで見える



WARRANTY INFORMATION | INFORMACION DE
GARANTIA | INFORMATIONS SUR LA GARANTIE |
INFORMATIONEN ZUR GARANTIE | 保証内容

- Lifetime warranty on all mechanical components
- 2 year warranty on electrical components
- 1 year warranty on rechargeable batteries
- Garantia de por vida en componentes mecanicos los componentes mecánicos
- 2 años en componentes electricos
- 1 año en baterias recargables
- Garantie à vie sur tous les composants mécaniques.
- 2 ans sur les composants électriques.
- 1 an sur les piles rechargeables
- Lebenslange Garantie auf alle mechanischen Komponenten.
- 2 Jahre auf elektrische Komponenten.
- 1 Jahr auf Akkus
- すべての機械部品上の永久保証
- 2電気部品に年
- 充電式電池で1年

www.niterider.com/warranty

8295 Aero Place, Suite 200
San Diego, CA 92123, USA

? 8:00 AM to 4:30 PM (PST) Weekdays

☎ (800) 466-8366 | INTL. +1 (858) 268-9316

✉ support@niterider.com

www.NITERIDER.com