

Please take a few minutes to read the instructions before using the product.  
Please charge and clean the product before using it. It's recommended to use the original charging cable only.

**Product Specifications**

Product Name	Dallas
Product Materials	ABS, Silicone
Battery	Li-Ion Rechargeable
Using Time	1 Hour
Charging Time	1.5 Hours
Waterproof	Splash-proof
Net Weight	Vibrador: 101.5 g Remote control: 16 g
Size	135*35*99 mm

**Size**

**Buttons Display**

**Instruction**

Controlled with button on vibrator:

- Press and hold the **On / Off** button for 1.5s to turn on / off the product.
- After the product is turned on, press the **On / Off** button again to start and switch between 3 thrusting patterns and 12 vibrating patterns.
- After the product is turned off, press the **On / Off** button again to reset the thrusting part to initial position.

Remote control:

- After the product is turned on by the **On / Off** button on the vibrator, press the **Power** button on remote control to start and switch between 12 vibrating patterns. Press and hold the **Power** button for 1.5s to stop vibrating, press again to restart vibrating.

**Light indicator**

- power on — light on
- working — light on continuously
- power off — light off
- charging — light flashes
- fully charged — light on permanently

**Maintenance**

- Wash it thoroughly with mild soap and clean water.
- Dry it with a clean towel.
- Store it in a cool, dry and dust-free place, avoid direct sunlight.

**Attention**

- This product is for adult use only; keep out of reach of children.
- It's recommended to use with water-based lubricants.
- Please stop using immediately if you feel uncomfortable during use.

**Especificaciones del producto**

Nombre del producto	Dallas
Materiales del producto	ABS, Silicona
Batería	Li-Ion recargable
Tiempo de uso	1 hora
Tiempo de carga	1.5 horas
Impermeable	A prueba de salpicaduras
Peso neto	Vibrador: 101.5 g Control remoto: 16 g
Tamaño	135*35*99 mm

**Tamaño**

**Visualización de botones**

**Instrucciones.**

Controlado con el botón que se encuentra en el vibrador:

- Presione el botón **On / Off** y manténgalo presionado durante 1.5 s para encender / apagar el producto.
- Después de encender el producto, presione **On / Off** de nuevo para iniciar y cambiar entre los 3 patrones de penetración y los 12 patrones de vibración disponibles.
- Después de apagar el producto, pulse de nuevo el botón **On / Off** para restablecer la pieza de penetración a la posición inicial.

Control remoto:

- Después de encender el producto con el botón **On / Off** en el vibrador, pulse el botón **Power** del mando a distancia para iniciar y cambiar entre los 12 patrones vibratorios. Presione el botón **Power** y manténgalo presionado durante 1.5s para detener la vibración, presione nuevamente para reiniciar la vibración.

**Indicadores de luz**


- Encendido — luz encendida.
- Trabajando — luz encendida continuamente.
- Apagado — luz apagada.
- Cargando — destellos de luz.
- Carga completa — luz encendida permanentemente.

**Mantenimiento**

- Lavar bien con jabón suave y agua limpia.
- Secar con una toalla limpia.
- Guardar en un lugar fresco, seco y libre de polvo, evitar la luz solar directa.

**Atención**

- Este producto es solo para uso de personas adultas; manténgalo fuera del alcance de los niños.
- Se recomienda usar con lubricantes a base de agua.
- Por favor, deje de usar inmediatamente si siente algún tipo de incomodidad durante su uso.



**Dear Valued Customer,**

Thank you for choosing Honey Play Box! We are dedicated to bringing you intelligent, Sleek, Luxury and Elegant Lifestyle products! Once you registered on our website, you will get the latest updates of our innovative products with creative ways of playing. Enjoy the amazing pleasure!

Honey Play Box Customer Service

1 Year BY REGISTERING YOUR PRODUCT ONLINE, YOU WILL VALIDATE YOUR 1-YEAR WARRANTY

FOR LATEST UPDATES, FOLLOW US!

@Honey Play Box

10 Year PROVIDING 10 YEARS OF QUALITY SERVICE AND SEXUAL WELLNESS PRODUCTS

**Quality**

Surpassing standards from Europe and America

**Material Safety**

All Honey Play Box products are manufactured using environmental friendly materials including Silicone and ABS plastics. They are harmless to human body.

**International Certification**

Honey Play Box products have passed EU ROHS certification and meet EU CE Directive and WEEE Directive. Honey Play Box products are "Green" meeting the official safety and environmental protection standard issued by agencies in Europe and North America.

**Additional Information:**

The EU CE Directive and the WEEE Directive are referred to as the "Twin Directives for Environmental Protection" or "Double Green Directives" and are used to restrict hazardous substances in electronic products including lead, cadmium, and mercury. ROHS stands for "Restriction of the Use of Certain Hazardous Substances"; and WEEE stands for "Waste Electrical and Electronic Equipment". Products that meet the standards set out in these two directives can be advertised as "Green Products".

**EU CE Directive:**

Is the collective name of a series of product standards issued by the European Union; enterprises complying with the standard may apply for CE certification mark on their products and labelling. Honey Play Box products surpass the standards set out by these directives and are authorized to use the mark identifying that the products comply with all EU requirements.

**WARNING!**

Proper maintenance and care may extend the product's service life. Before using the product, please read the following safety instruction carefully.

- Please comply with the following before using the product: Clean the product completely. Scrub it with an antibacterial soap and then wash with clean hot water; at last, wipe it gently with towel or soft cloth.
- During using the product
  - NO using massage oil or hand cream as lubricant.
  - NO using silicon-based lubricant, because it'll damage the organosilicone surface.

Reminder: Do not use any cleaning agent containing alcohol, gasoline or acetone to wipe the product. Avoid direct solar radiation and long-time exposure to the high-temperature environment. The product shall be stored in a clean and dry place without contact with other plastic products.

**Maintenance of the Built-in Battery.**

- This product uses rechargeable batteries. A new battery could play its full effectiveness after two or three charging and discharging processes.
- A battery can be charged or discharged for over 100 times and will go matured finally. After being charged fully, the battery shall be disconnected with the charger, or overcharge may reduce the battery life.
- When the product is idle, the electric quantity of fully charged battery will lose gradually.
- If the product is placed in a too hot or cold place, it will reduce the battery capacity and shorten the battery life. If the battery is too hot or cold, the battery life will be also short even though it is charged fully.

**Battery Warning!**

- When the battery damaged or tampered with, it could cause fire or chemical burn. Explosion may happen when the battery is damaged.
- The battery shall be disposed in accordance with the local laws and regulations. If possible, please recycle it. Users shall not take out or replace the battery by themselves; otherwise, the risky operation may damage the product.

Reserve alguns minutos para ler as instruções antes de usar o produto.  
Por favor, carregue e limpe o produto antes de usá-lo. Recomendamos usar apenas o cabo de carregamento original.

**Especificações do produto**

Nome do produto	Dallas
Materiais do produto	ABS, Silicone
Bateria	Li-Ion recarregável
Usando o tempo	1 hora
Tempo de carregamento	1.5 horas
À prova d'água	Prova de água
Peso Líquido	Vibrador: 101.5 g Control remoto: 16 g
Tamanho	135*35*99 mm

**Tamanho**

**Exibição de botões**

**Instrução**

Controlado com botão no vibrador:

- Presione e segure o botão **On / Off** por 1.5s para ligar/desligar o produto.
- Depois que o produto for ligado, pressione **On / Off** novamente para iniciar e alternar entre 3 padrões de impulso e 12 padrões de vibração.
- Depois que o produto for desligado, pressione **On / Off** novamente para redefinir a parte de impulsão para a posição inicial.

Controle remoto:

- Depois que o produto é ligado pelo botão **On / Off** no vibrador, pressione o botão **Power** no controle remoto para iniciar e alternar entre 12 padrões de vibração. Pressione e segure o botão **Power** por 1.5s para parar de vibrar, pressione novamente para reiniciar a vibração.

**Indicador de luz**

- ligar — luz acesa
- funcionando — luz acesa continuamente
- desligar — luz desligada
- carregando — a luz pisca
- totalmente carregado — luz acesa permanentemente

**Manutenção**

- Lave bem com sabão neutro e água limpa.
- Seque-o com uma toalha limpa.
- Armazene-o em local fresco, seco e livre de poeira, evite a luz solar direta.

**Atenção**

- Este produto é apenas para uso adulto; Mantenha fora do alcance de crianças.
- Recomenda-se o uso com lubrificantes a base de água.
- Por favor, pare de usar imediatamente se você se sentir desconfortável durante o uso.