
1 Product Overview



- Battery pocket
- Input connector
- Temperature controller

- (5) Battery capactity Indicator light
- **(6)** 5V USB port(phone charger)
- (7) Mini-USB charging port
- Battery button


What's in the box: Heated Apparel x1 Li-polymer Battery x1 USB Cable x1 Zipper Bag x1

2 User Guide


Step 1. Connect battery with jacket / pants.

1. Plug battery connectors as shown below.

Jacket



Pants



Step 2. Turn ON / Turn OFF


1. Turn ON:

Press and hold the temperature controller 3 Seconds until the red color Turn ON (high temperature)


2. Turn OFF:

Press and hold the temperature controller 3 Seconds until the LED Turn OFF.

Jacket



Pants



Step3. Adjust heat level

Tap (click once) the temperature controller to select your desired temperature.



3 Battery Charging and Maintenance

Battery Care

- Battery must be fully charged before storage.
- At least once every 6 months of storage thereafter.

CAUTION

Do not tamper with components.


Danger of explosion if battery is incorrectly replaced.

Do not dispose of in fire or expose to excess heat.

Do not crush, puncture, incinerate or short-circuit.


1.Charging your battery. (Fully charge before use)

1 Connect battery with charger. 2 Plug charger into a power outlet.



2.Check battery status

- Click the Battery button to check battery percentage status.
- 2 LED indicator will flash briefly to indicate remaining charge as:



4 Wash and Care

Please **remove the battery** before cleaning.



Hand wash only



Do not iron





Do not bleach Do not dryclean

5 Warning

- Do not use on an infant or child.
- Do not use on a person who is paralyzed or has skin that is sensitive to temperature changes.
- Do not use on a sleeping or unconscious person.
- Do not use in an oxygen enriched environment or near equipment that emits oxygen.
- Do not unplug by pulling on connecting cord.
- Do not use pins or other metallic fasteners to hold it in place.
- Do not tamper or modify wiring or heating elements.
- Do not expose battery to liquids.
- Do not disassemble battery.

6 Ventureheat One(1) Year Limited Warranty

Thank you for purchasing this Venture Heat product. This Limited Warranty covers defects in heated electronic components and battery for one (1) year from the initial date of purchase from an authorized Venture Heat dealer. This warranty is nontransferable, proof of purchase is required for warranty service.

Damages to the heating system or parts resulting from modification, accident, fire, flood, misuse, unauthorized service or negligence outlined in the instructions printed herein will void the warranty.

Warranty does not cover wear and tear of the garment; fabric, zipper and other accessories are not covered under this warranty. Under no circumstances will Venture Heat be liable for the incidental, consequential, or punitive damages resulting from the product, whether or not the product is found to be covered by this warranty.

For more warranty information contact your local Venture Heat distributor:

USA: service@ventureheat.com

Australia: www.zarkie.com.au

7 Questions?

USA • CANADA

service@ventureheat.com Toll Free 1-877-261-9477

3 English English 4