



PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR RETRO POGO STICK.  
KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

VISIT OUR WEBSITE AT: [www.pogosticks.com](http://www.pogosticks.com)

Always adhere to the following age and weight restrictions: RETRO POGO: For ages 8 and up, 80 to 160 lbs.

IF ANY PARTS ARE MISSING, DO NOT RETURN POGO TO THE PLACE OF PURCHASE  
WE WILL RUSH YOU ANY MISSING PARTS AT NO CHARGE.


The rubber tip on your pogo is installed at the factory. Should the tip become lost or damaged, replace it immediately.  
**NEVER** use your pogo without the tip properly in place.

## TIPS FOR PROPER USE OF YOUR POGO

- ☆ Always wear protective gear, helmet, knee and elbow pads.
- ☆ Always use your Pogo on a hard surface. NEVER use your Pogo on grass or dirt.
- ☆ Have an adult check your Pogo before first use and on a regular basis.
- ☆ NEVER use your Pogo with bare feet. Always wear shoes.
- ☆ Do not push the Pogo away from you. You cannot balance this way and you could damage the Pogo.
- ☆ Hold the Pogo vertically, and develop balance by pulling the Pogo up with you.
- ☆ Do not use your Pogo without the rubber tip properly in place.
- ☆ Make sure all of your friends are instructed on the proper way to use your Pogo.
- ☆ Follow the lubrication instructions below.



WRONG



RIGHT

## LUBRICATION INSTRUCTIONS

Proper lubrication can be maintained with silicone spray, do not use oil or grease. During heavy use your pogo should be cleaned and lubricated every few days. Lubricate the brass plated center shaft where it passes through the bracket above the spring. Turn the pogo stick upside down and lubricate the center shaft where it enters the foot rest.


## POGO REPLACEMENT PARTS

A new replacement part form will be sent with your order.

Model #2025 Retro Tip	\$1.50	_____
Receive one free tip with the purchase of two or more tips		
Model 2025 Retro Spring	\$3.00	_____

Postage and handling  
(Choose One)

Within the U.S.A. and Canada Only	\$3.00	_____
All other Countries	\$7.50	_____
<b>Total</b>		_____



Make check or money order payable in US Funds to:

S.B.I. Enterprises, P.O. Box 628, Pogo Plaza, Ellenville, NY, USA 12428

◦ MAIL PARTS TO: NAME .....

ADDRESS .....

CITY ..... STATE ..... ZIP .....

# Important – Please Note

The Retro Pogo Stick is designed for user weights 80 to 160 lbs.

1. The spring is not adjustable.
2. Spring is deliberately “tight” in all new Retro Pogo Sticks
3. It takes several successive bounces to gain the momentum necessary to compress the spring
- 4. Do not worry if the spring initially feels “tight”. It takes some “jumping time” for it to set.**
5. The spring cannot be compressed by pushing down on the pogo with your hands or one foot. If the user is not able to balance well enough to achieve several successive jumps, have a helper act as a spotter. The spotter should stand behind the jumper, wrapping his/her hands around the jumper. The spotter's hands should go over the jumpers on the handlebars. When the jumper bounces the spotter should pull up steadying the jumper. Allow gravity to bring the jumper back down. With a little practice the spring will compress and the spotter will no longer be needed.