

# LEVONA

SCENTING

## INSTRUCTION MANUAL

Attached; Warranty Card

Please carefully store the instructions and warranty card for further reference. Please read all instructions before using the device.

### I .Please adhere to the following basic safety precautions at all times

**⚠ WARNING: MAY CAUSE ELECTRIC SHOCK OR FIRE HAZARD.**


#### **WARNING! WHEN INSTALLING:**

1. Do not use unsafe plug or power.
2. Do not install the device within reach of small children.
3. Do not install the device in an unstable environment that is prone to collapsing.
4. Do not tilt the device.
5. Keep the device away from fire and heat sources.
6. Except for the atomizer, the housing material is not resistant to corrosion.
7. Do not use device in a high temperature or wet environment.
8. Do not use flammable, explosive, corrosive, or other hazardous solvents around the device.

**⚠ WARNING: MAY CAUSE PERSONAL INJURY OR PROPERTY DAMAGE**

#### **WARNING**

1. Ensure stability of installation area.
2. Install the device in a ventilated space.
3. Do not block the sprayer when the device is working.
4. Do not spill water or conductive, corrosive liquid on or in the device.
5. Do not operate device all day. Suggested average daily usage time should not exceed 14 hours, and the third level is recommended.
6. Cut off the power in an extreme weather environment.



Voltage: 12V  
Power: 12W  
Capacity: 500ml  
Volume: ≤35dba  
Weight: 1.8kg  
Coverage: : 800-1200m³  
Size: L190\*W99\*H250mm



Atomizer head  
Nozzle  
Fragrance oil bottle

Approved Certificate: CE, FCC, RoHS, CNAS Etc.  
Application Place: Hotel, 4S Car Store, Brand Shop, Bar, Public Area ETC.

### II. Function Description

#### **One Button, Two Indicator Lights**

1. Button Description:
  - A. Shortly press button to turn on/off
  - B. Hold button to perform system reset
2. Indicator Lights:
  - A. Green Light: Scent Status  
Green Light On: Device Active  
Green Light Off: Device Paused
  - B. Blue Light: Network Status  
Blue Light Quickly Flashing: Not connected to Bluetooth  
Blue Light Slowly Flashing: Connected to Network  
Blue Light Solid: Connected to Bluetooth


#### 4. Notes:

- A. The buzzer rings once the device is turned on.
- B. The buzzer rings three times to indicate that the device has connected to the network/Bluetooth.

#### 5. App operation; please refer to the App manual

#### 6. Reset Operation:

To reset, find the hole near to the indicator light of the device, use a toothpick or other small tool to press the hole for 5 seconds, You will hear the " dip" sound when you reset the system. (As shown the right picture)



### III . Troubleshooting

#### 1. The PCB won't work:

- A. PCB Damage – Replace PCB
- B. Dead Battery – Replace Battery
- C. Power Malfunction – Check Power Cable

#### 2. Equipment won't work. PCB displays normally:

- A. Pump System Broken – Replace Pump
- B. Time Setting Error – Check Time Settings
- C. Inner Circuit Problems – Check Inner Circuit (Multimeter)

#### 3. Abnormal Noises:

- A. Pump is Broken or Loose – Adjust or Change Pump
- B. Trachea Cable Problematic – Check Cable Connection
- C. Internal Structure Damaged – Adjust or Change parts

#### 4. Machine Works. Weak or No Scent:

- A. Blocked Nozzle – Clear & Clean Nozzle
- B. Pipette Disconnects – Reconnect Pipette
- C. Aged Pump System – Change Pump
- D. Blocked Atomizer – Clean Atomizer
- E. Impurities in Oil – Replace with Pure Oil

#### 5. Oil Leak

- A. Tilted Equipment – Straighten Machine
- B. Leaking Atomizer – Replace Atomizer

### IV. Machine Maintenance

For best performance, clean equipment every 2-3 months. Be sure to power off when cleaning and do not use with wet hands or in a wet environment.

### V. Long-Term Non-Use

1. Power off and secure power cord.
2. Clean filter components.
3. Place the deodorant package (which contains activated carbon) in the device or package to prevent residual substances from producing foul odors.
4. Equip dust cover and place in a cool, ventilated area.

### VI. Accessories and Spare Parts

- |   |   |
|---|---|
| • Aroma Diffuser: 1PC                     | • Key: 2PC  |
| • Adapter: 1PC                            | • Screws: (including plastic expansion tube): 2PC |
| • Bracket for installing on the wall: 1PC | • Manual: 1PC                                     |
| • Cap: 1PC                                | • App Manual: 1PC                                 |
| • Air Conditioning Tube: 1PC              | • Warranty Card: 1PC                              |

### VII. After-Sales Service

1. Free technical solutions and installation guidance.
2. Free online FAQ resources and scent-marketing advice.

[levonascenting.com](http://levonascenting.com) | [help@levonascent.com](mailto:help@levonascent.com)

LEVONA  
SCENTING

### VIII. Hanging the Machine

1. Clean the surface.
2. Peel and hang the sticker.
3. Attach the machine into sticker brackets.



# LEVONA

SCENTING