



## INSTRUCTIONS



## PROMAX™ INLINE CONNECT SYSTEM

Inline Refrigerator/Ice Maker Filter Instructions

**FOR TECHNICAL SUPPORT PLEASE CALL**

**1-800-544-3533**

**OR email:**

**[customerservice@propurusa.com](mailto:customerservice@propurusa.com)**



# NEW PROPUR™ PROMAX™ INLINE CONNECT SYSTEM

Model PM100-IC



## 1. Package Contents

- a. PM100-IC filter assembly
- b. Compression fittings (attached)
- c. Mounting clip and screw

## 2. Tools and Hardware Required for Installation

- a. Adjustable wrench
- b. Bucket
- c. File
- d. Rags
- e. Pliers
- f. Tube cutter
- g. Saddle valve and 1/4" tubing (if not currently installed) or for a new installation-check your local hardware store for a refrigerator installation kit.

## 3. Installation



**IMPORTANT** – TURN OFF REFRIGERATOR/ICE MAKER WATER SUPPLY LINE BEFORE INSTALLING. SHOULD THIS BE A NEW INSTALLATION, INSTALL SADDLE (SHUTOFF) VALVE WITH SUPPLY LINE TO REFRIGERATOR/ICE MAKER. THE PM-100-IC IS FOR COLD WATER USE ONLY.

- a. The PM100-IC comes with compression fittings designed for 1/4" tubing.
- b. Select a suitable location for the PM100-IC filter such as behind the refrigerator or beneath the kitchen floor (basement). Location should be easily accessible for replacement.
- c. The filter splices into standard 1/4" copper or plastic refrigerator water supply line. Place a bucket under the supply line when cutting to catch any residual water that may drain out. Deburr both cut ends with file of the supply line before installing the filter.
- d. Attach the water supply line to the INLET side of the PM100-IC filter by
  - i. Slide nut onto inlet water line
  - ii. Slide brass compression ring onto tube
  - iii. Insert tube into inlet end of filter and tighten nut using backup wrench (so that fitting does not turn into filter)
- e. Place the OUTLET of the filter into an empty bucket and slowly turn on the water. Allow the filter to flush for 5-10 minutes or until water is clear. This initial flushing allows for any carbon particles to be flushed out of the filter before attaching to your refrigerator.
- f. Once flushed, turn off water supply to continue installation
- g. Connect the supply line going to the refrigerator to the OUTLET side of the filter by
  - i. Slide nut onto outlet water line
  - ii. Slide brass compression ring onto tube
  - iii. Insert tube into outlet end of filter and tighten nut using backup wrench (so that fitting does not turn into filter)
- h. Turn on water. Check for leaks, retighten fittings, if necessary. DO NOT OVERTIGHTEN!
- i. Use the mounting clip and screw to attach the filter to any nearby support to limit stress on the tubing. Allow easy removal for filter assembly replacement.
- j. Write the installation date on the filter.

#### 4. IMPORTANT

- a. Maximum operating pressure is 125 psi. If pressure is anticipated to exceed 125 psi, use a pressure reducing valve, not included.
- b. Should you notice a difference in the taste of the water after use, please replace the complete assembly. Filter and housing is one self-contained unit.
- c. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection.
- d. PM100-IC Specifications
  - Maximum flow - .50gpm
  - Maximum pressure -125psi
  - For cold water use only
  - Minimum temperature -35° F
  - Recommended replacement-750 gallons or up to 9 months



**ProMax™**  
FILTER TECHNOLOGY

Shower Filter  
Counter Top  
Under Counter  
Whole House  
Filtration Systems

#### PROPUR™ LIMITED WARRANTY

Lincoln-Remi Group, LLC d/b/a Propur ("PP") sells its products with the intent that they are free from defects. PP warrants to the original retail purchaser/consumer that its products will be free of defects in material and workmanship under normal use for a period of 9 months for the ProMax™ 100 Inline Connect Refrigerator/Ice Maker ("Warranty Period"). PP will replace or repair any product, at its sole discretion, during the Warranty Period. Any damage caused by misuse or abuse; accident; improper installation; dropped product; failure to provide recommended maintenance; transportation damage; neglect; environmental conditions; or any other conditions whatsoever that are beyond the control of PP are excluded from this warranty. This express limited warranty shall be the sole and exclusive warranty. **ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS OR FITNESS FOR ANY PARTICULAR PURPOSE OR ANY OTHER POTENTIAL OBLIGATION ON THE PART OF PP WITH RESPECT TO PRODUCTS SOLD BY PP ARE DISCLAIMED. EXCEPT FOR ANY EXPRESS WARRANTIES, ALL PROPUR PRODUCTS ARE SOLD "AS-IS".** PP shall not be held liable for any incidental, consequential or special damages of any sort whatsoever. The liability of PP is limited to the original retail purchaser and to the repair or replacement of defective parts during the Warranty Period. No refunds will be given at any time. The liability of PP terminates upon the expiration of the Warranty Period or transfer of product ownership.

To obtain warranty service on your Propur product, mail the product with your dated sales receipt as proof of purchase, postpaid, to the following address:

Propur, 1200 Benstein Rd, Commerce Twp, MI 48390. NO C.O.D.'s

This warranty provides you with specific legal rights. You may have additional rights which may vary from country to country. Because of individual country laws and regulations, some of the above limitations and exclusions may not apply to you.

V05252016