

ASSEMBLY INSTRUCTION


Remove all items from the carton. Verify all pieces before assembly.


PART LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest Screw	12	1	Backrest Post Bellow
2	1	Base	8	1	Seat	40	2	Backrest Post Bellow Screw
3	1	Seat Post	9	1	Mechanism	13		
4	1	Seat Post Cover	10	6	Mechanism Screw	14	1	M5.M6 Size Allen Wrench
5	1	Backrest		1	Backrest Tight Screw + Washers			
6	1	Backrest Post	11					














MECHANISM INSTRUCTIONS:

- (A) Back angle adjustment lever.
- (B) Combination seat / back angle adjustment lever with infinite lock.
- (C) Seat height adjustment lever.
- (D) Forward tilt lever
 - *While seated, lift lever B and then leanback to activate locking mechanism;
 - *Pull lever D backward to allow seat to tilt forward- or -push lever D forward to straighten seat;
 - *To lock in desired position, push lever B downward.
- (E) Tension control knob-Turn colockwise to increase tension and counter - clockwise to decrease tension.
- Sliding seat: Seat depth adjusts for different user leg lengths.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
 DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
 DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHTENED
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.

 DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION.

 FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

 NOTE:SOME SCREWS MAY BE PREASSEMBLED.

 IF PREASSEMBLED, IGNORE ASSEMBLY INSTRUCTIONS.