

### **⊕** TABLE OF CONTENTS **₽**

In the box $1$
My PoooliPrinter parts 2
How to use 3
Download the Poooli App 4
Bluetooth connection 5
Magnetic beak 6
How to replace a paper roll 7

# - IN THE BOX -













**USB Cable** 



Power Button







#### Powering ON/OFF

Hold power button for 2 seconds to turn ON/OFF PopoliPrinter.

#### Light Status

- Continuous: Standby / Charging Completed
- Slow Flash: Charging / Updating
- Fast Flash: Out of paper roll / Cover Open / Low Battery

#### Recharging

Fully recharge your device before the first time use. It can be recharged from a USB charger. It takes about 90 minutes to fully recharge.

3

## @ DOWNLOAD THE POOOLI APP &



# - BLUETOOTH CONNECTION -

- ◆ Open the App and click "CONNECT".
- Connect to the device by searching for Bluetooth or Double tap the Power Button on your PoooliPrinter to print a QR Code and scan to connect.



### @ MAGNETIC BEAK P

You can simply move the magnetic beak as follow:








## - HOW TO REPLACE A PAPER ROLL

- ♦ Hold your PoooliPrinter vertically as shown on Figure 1
- ♦ Push down the cover as shown on Figure 2
- ♦ When replacing a paper roll, place the roll of paper coming out in the direction as shown on Figure 3
- Note: Some paper rolls may have to be placed upside-down.
- Once the paper roll is properly installed you can close the cover back to its original shape.











YOUR DAILY LIFE







ENJOY IS% OFF YOUR ORDERS

LIFETIME WITH CODE LIFEIS

PLEASE TAG US ON SOCIAL MEDIA

FOR YOUR CHANCE TO BE FEATURED!





