Quick Start Guide MONSTER® RC

For complete operational guidelines please refer to your user manual.

Connect Power & Charge



- 1. Connect the power cable to the speaker.
- 2. Plug the cable into a wall outlet.
- 3. Rove speaker will automatically begin to charge.
- 4. Press and hold the Power button (1) to turn the speaker on.

BEFORE FIRST USE: Charge the unit for **6 hours.** When fully charged the WHITE LED will stay solid When low on battery the **WHITE LED** will flash rapidly. To Indicate battery level Press (3 seconds) the **POWER** button.

Manual Bluetooth Pairing



- 1. Activate Bluetooth function on vour music device.
- 2. Place music device and speaker within pairing range (~3 ft).
- 3. Press and hold Bluetooth button 🖈 on speaker to enter pairing mode (flashing BLUE LED).
- Connect to "Monster Rove" on your music device.
- 5. Speaker will automatically connect to music device (solid BLUE LED).

LED Light Functions



Turn Light ON/OFF

Press and hold the Light button or to turn LED lights on/off.

Change Color

Press the Light button **O to cycle through different colors:











Change Brightness

While pressing and holding the light button 💆 , press Volume Up + to increase brightness. Press Volume Down — to decrease brightness.

Wireless Connection (Additional Speaker Sold Separately)



Sync Together & Play Two ROVE Speakers

- 1. Connect music device to one speaker via Bluetooth, this will be the Transmiting speaker. (page 9 for reference)
- 2. Press and Hold the EZ-SYNC button for 3 seconds on the Transmitting speakers to enter sync mode (WHITE LED next to EZ-SYNC button will flash). Transmitting speaker will automatically search for the nearest EZ-SYNC compatible speaker to connect to.
- 3. Both speakers are connected when EZ-SYNC light stays solid.
- 4. Speakers can be no further than 30ft apart for EZ-SYNC to work





DONT MISS OUT

EXCLUSIVE DEALS FIRMWARE UPDATES PRODUCTS RELEASES

SUBSCRIBE

http://mymonsteraudio.com/