

MONSTER®

# FLAME


## QUICK START GUIDE

MODEL: MNFLAME



### Power

- 1 Connect the speaker to an external power source using the included AC power cable.
- 2 Press the **POWER** button to turn the speaker **ON**.



(Press)

### Bluetooth Pairing

- 1 Place your music device within 3 feet of the speaker.
- 2 **Bluetooth mode** is automatically entered when speaker is powered on (*BLUE LED Bluetooth & EZ-Play TX LED will quickly flash*).
- 3 Select "**MONSTER FLAME**" on your smart device's **Bluetooth** menu to pair with the speaker.



### Light Modes

- 1 **PRESS** the **Light Mode Button** to turn on the ambient light. (Press)
- 2 **PRESS** the **Light Mode Button** to cycle through the modes. (Press)
- **HOLD** (~3 sec.) the **Light Mode Button** to turn off the ambient light in any mode. (Hold ~3 sec.)

### Zen Modes

- 1 **HOLD** the **Zen Mode Button** (~3 sec.) to start music in any mode. (Hold ~3 sec.)
- 2 **PRESS** the **Zen Mode Button** to cycle through song selection. (Press)
- **REPEAT** step one to exit Zen music mode. (Hold ~3 sec.)

~30 feet max connection range after pairing. Devices out of range may suffer disruption or loss of signal.

For full detailed instructions, please refer to the user manual.