



- PAGE 80/80
- 791 KOV 2 Dragons
  - 792 KOV Ytzy2
  - 793 KOV Ytzy1
  - 794 KOV 2
  - 795 KOV 2 Plus
  - 796 Oriental Legend
  - 797 Oriental Legend Super
  - 798 Oriental Legend SP
  - 799 The Killing Blade Plus
  - 800 Martial Masters
- TIME 99

# HEROES 4

GUAN 55400 2.1  
ZHANG 62800 2.3

## NINE DRAGONS

<http://www.igs.com.tw>

**FREEPLAY**



## System Settings

Please push the side tact switch to enter the system setting menu.



(1) IO test: Use this menu to test the working status of the coin selector, joysticks and buttons. (The color of the corresponding icon is initially blue, then turn yellow when press down, and then turn red when release).



- (2) Coin insert mode: use this menu to set one coin game, 2coins game, .... and 1P alternative function.
- (3) Exit mode: use this menu to set how to exit from the current game. The user can choose exit from long pressing "EXIT" button or pressing "START" button with a coin insert event simultaneously.
- (4) Exit automatically: if the game player is absent then the game itself will go to idle state. the system will exit the current game and go back to the initial demonstration interface after 3 minutes. However, the user can also choose "Exit automatically after 3 minutes" or "Never exit automatically".
- (5) Game selection mode: 2 independent selection modes can be set in this menu bar.
  - A. Only enable game selection when a valid coin is accepted.
  - B. Without any limitation, enable game selection unconditionally.



## System Settings

### 6) Individual game setting



A. Game difficulty level and life number setting. When the user pushes the A button in 1P console in the game setting menu, he can move the joystick to choose which game he needs to set, and use A button to change the difficulty level and B button to set initial life number. The life number setting will automatically disabled when the user chooses a game with no life number setting. In some cases, if the user needs to update all other game settings according to the current setting, he must push C button in the 1P console, and enable "Use the current setting for all other games". The user can still press D to return back.





## System Settings

B. Game list edit. If the user needs to show or hide some games. (all games are shown by default) please press B button in the game setting menu to edit the game list. Use the joystick to choose the proper game and press A button to toggle the game state from "Show" to "Hide" and vice versa. Once a game is set to the "Hide" state, the color of the corresponding name will turn to gray. The user can also push B button to show all hidden game list. If only one specific game is need to be shown, please use the joystick to select it and press C button, then the main board will go to this game only after power on. Press D button to return back.





## System Settings

### (8) Saving and Exit.

Once the mentioned operation is completed, please press D button continuously to go back to the initial game setting menu, and use the joystick to move the menu bar to the "Saving and exit" option, then press A button to confirm. The following dialog will pop up, and please DO NOT turn off the power, the system will reboot automatically.

### (9) Restore the factory settings and exit.

If you want to restore the factory settings, please choose the menu of "the factory setting and exit" and press the A button to make a confirmation.

