


## INSTRUCTIONS - DISPLAY

P1C/04, P1C/05, P3C/02, P3C/03, P3C/04, P3C/07, P3C/08, P3C/09



AUTOMATIC MOVEMENT - MIYOTA 82S7 - MADE IN JAPAN

10ATM/100M WATER RESISTANT

### WINDING THE MAINSPRING

Unscrew the crown, until you hear a click (position 1). Automatic winding watch can also be hand wound by turning the crown clockwise in position 1. Wind 15-20 times and it will start to move, after slightly shaking.

### SETTING THE TIME

1. Unscrew the crown, until you hear a click.
2. After hearing the click, pull out the crown.
3. Adjust the time, by rotating the crown upwards or downwards.
4. After the time has been set, push the crown back and screw it into normal position.

# TIME READING

DISPLAY

EXAMPLE 1




10:31:20

HOURS: 10AM

MINUTES: 31MIN

SECONDS: 20S

EXAMPLE 2



6:10:40

HOURS: 6PM

MINUTES: 10MIN

SECONDS: 40S