



BERNINI™ F O U N T A I N S

FlexEnd Watering Wand with Nozzle


A few ideas for how to use your FlexEnd Watering Wand™



1 Assemble FlexEnd Watering Wand™ To Hose



2 Storing your hose



INSTRUCTIONS:

1. Remove the FlexEnd Watering Wand™ from the package.
2. Ensure the spray nozzle (included) is tightened securely to the outlet of the FlexEnd Watering Wand™ (figure 1). Make sure only 1 rubber washer is in place.
3. Attach the other end of your FlexEnd Watering Wand™ inlet to the water hose (figure 1). Ensure only 1 rubber washer is in place.
4. Turn on the faucet from your home's water supply to start using the FlexEnd Watering Wand™.
5. When opening or closing hold the Nozzle Collar and twist the Nozzle End (Figure 1 *A & *B), **DO NOT OVER TIGHTEN IN THE FULL OPEN OR FULL CLOSED POSITION!**

LIMITED ONE YEAR WARRANTY

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. This product has a one year limited warranty on all materials and workmanship. Bernini™ warrants the original purchaser of this product that the product will be free from manufacturing defects in workmanship and material for a period of one (1) year from the date of original purchase. If within one (1) year this product fails due to defect in material or workmanship, Bernini™ will repair, replace or supply any defective part(s) at their discretion. The purchaser must contact Bernini™ and provide a description of the defective part, including digital pictures if requested, with this original purchase documentation as validation of warranty coverage. This warranty does not cover or apply to: (a) damage to the product due to misuse, mishandling, and abuse, (b) products not used in accordance with instructions, (c) product not assembled or installed according to instructions, and (d) normal wear and tear.

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. YRDLLC shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

WARNING

- The water in ANY watering wand may become contaminated & cause serious health effects.
- Strangulation hazard. FlexEnd Watering Wand™ wrapped around neck may cause serious injury or death.
- Keep out of reach of children.
- For general OUTDOOR use ONLY in applications under 80 psi.
- DO NOT use this FlexEnd Watering Wand™ for commercial applications, in hot water applications, or high pressure applications. Doing so may cause serious personal injury and or damage or destroy the product.
- DO NOT leave this product unattended when it is under pressure.
- This product is NOT A TOY.

001300-03 BFCW US Inst rev2b

Contact Customer Service

+1 (619) 449-2392

customer@berninifountains.com

9545 Pathway Street, Santee, CA 92071

Customer Service hours: Monday - Friday 8:30am to 4:00pm PST / 11:30am to 7:00pm EST

On the web: www.berninifountains.com | Facebook and Pinterest: Bernini Fountain Company | Instagram: @berninifountains
World Wide Patents Pending | Made in China | Designed in the USA

January 2021© Yeiser Research & Development LLC and Bernini Fountains™ Fountains. All rights reserved. Trade names, product names and logos used in this document are the trademarks or registered trademarks of Yeiser Research & Development LLC, Santee, CA 92071