

TAYLOR HOME®

OPTIMAL TEMPERATURES

	SAFE ZONES	DANGER ZONES
REFRIGERATOR	32°F-40°F	42°F +
FREEZER	20°F-0°F	10°F +

HOW TO USE:

Hang or stand thermometer in the fridge or freezer to help monitor food safe temperature zones. Keeping your appliances at the proper settings will help with energy usage and food spoilage.

CLEANING AND CARE:

Handwash only. Do not immerse in water or put in dishwasher.

ONE (1) YEAR WARRANTY

For warranty information
please call 1.888.843.3905
or visit us online at:
SHOPTAYLORUSA.COM



3507-2.1.17

MODEL 3507
©2017 Taylor Precision Products
Seattle, WA 98134

Place
Sticker
Here



Made in China

