



MORBARK®



YOKE
LOCK

⚠ DANGER
CRUSH HAZARD
Moving parts can crush.
Always use yoke locks.
Follow lockout procedures
before servicing.

MADE FOR **MORE** TO KEEP PACE WITH **YOU**

PSP POLE AND POST PEELER

The **Morbark PSP Pole and Post Peeler** peels logs from 6' to 25' in length (1.8 m – 7.6 m) and 3" to 12" in diameter (7.6 cm – 30.5 cm). It can peel up to 40 feet per minute (12.2 m/min). All Morbark post peelers use a split peeling head with carbide-tipped cutterhead teeth to remove bark and knots and planer knives to provide a smooth surface with only one pass through the machine.

FEATURES AND BENEFITS

- Center section complete with debarking mechanism, combination carbide teeth and planer knife cutterhead with hydraulic table lock assembly
- 20' (6.1 m) infeed conveyor section with kicker assembly and hydraulic drive
- 20' (6.1 m) outfeed conveyor section, hourglass roll design, with 2-way kicker assembly and hydraulic drive
- Hydraulically controlled infeed shoe and top yoke assembly
- Support legs 39" (99.1 cm) from bottom of leg to top of infeed conveyor section
- Motor base (specify frame size) and V-belt drive





MORBARK® PSP POLE AND POST PEELER SPECIFICATIONS

GENERAL	US	METRIC
Capacity (diameter range)	3" – 12"	7.6 cm – 30.5 cm
Capacity (length)	6' – 25'	1.8 m – 7.6 m
Power	Electric, diesel or PTO	
Horsepower	50 hp	37.3 kW
Production rate	Up to 40 FPM	12.2 m/min
Weight	11,000 lb	4990 kg
Length	25' infeed/outfeed	7.6 m infeed/outfeed
Width	10'	3 m
Height	8' with blower, 7'2" without blower	2.4 m/2.2 m
Discharge	Bark auger & blower, barn sweep	
Debarker type	Split cutterhead debarks, then planes surface	

OPTIONS INCLUDE

- Machine to accommodate 30' (9.1 m) poles (25' (7.6 m) infeed and outfeed)
- Bark blower and feed auger for waste removal complete with drive, elbow blowpipe, and connection collar
- Blowpipe 8" x 10" (20.3 cm x 25.4 cm) extension section with connecting collar
- Infeeds and outfeeds sold separately (complete with drive)
- Elevated operator's console, complete with access ladder, seat, and hose hook-up
- All-weather cab (operator's console must be added when ordering cab)
- Side-mounted combination air conditioner/heater unit for cab enclosure

Specifications may vary with equipment options

Updated 2/26/2020

