

POWERHORN Remote Siren f/A cXY PH508L + bgfU Uhjcb UbX CdYfUhjb[+ bgffi Wjcbg

INSTALLATION AND OPERATING INSTRUCTIONS

- 1. Set the Housecode dial on the POWERHORN to the same letter as your security system
- 2. If you want to control the POWERHORN from other types of X10 controllers, set the Unit Code dial on the POWERHORN to any unused number between 1 & 16.
- 3. Plug the POWERHORN into an AC outlet (not one that is controlled by a wall switch, in case the switch accidentally gets turned off).
- 4. To test the POWERHORN, trip your alarm system. The POWERHORN will sound for as long as the alarm in the security system console sounds, and then shut off a few seconds after you disarm the alarm.

WARNING: The POWERHORN is extremely loud. To avoid permanent hearing damage, do not stand too close to it when you trip the alarm.

5. To trip the POWERHORN from any X10 controller (if you hear a strange noise at night, for example): Press Unit Code-ON, then Unit Code-OFF, then Unit Code-ON, repeatedly. The POWERHORN will sound for as long as you keep pressing ON and OFF and will stop a few seconds after you stop pressing buttons. Or press All Lights On, then All Units Off, repeatedly. The POWERHORN will sound for as long as you keep pressing All Lights On, followed by All Units Off and will stop a few seconds after you stop pressing buttons.

The Owner's Manual for the Security System describes the full installation process for the Security System, and should be referred to in addition to these instructions.

: "7"7"75| H&B ! H& & 89J = 97CA D@9GK +k D5FH%) C: H&9: 77F| @9G"CD9F5H&B & G| 6>97HHC H&9: C@@CK &; HK C'7CB8 +H&BG. fW: H& & 89J = 9' A 5MBCH 75| G9' < 5FA: | @ BH9F: 9F9B79Z 5B8 fW: H& & 89J = 9' A | GH 5779DH 5BM BH9F: 9F9B79Z 5B8 fW: H& & 89J = 9' A | GH 5779DH 5BM BH9F: 9F9B79Z 5B8 fW: H& & 89J = 9' A | GH 5779DH 5BM BH9F: 9F9B79Z 5B8 fW: H& & 89J = 9' A | GH 5779DH 5BM BH9F: 9F9B79Z 5B8 fW: H& & 89J = 9' A | GH 5779DH 5BM A C8 = 35H&BG A 5M69Z 5B9Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5BM7 < 5B; 9GZ A 589Z HC H&9 | B + G" 5MBZ A 5MBZ

%&\$ 85M@A +F98 K 5FF5BHM L%\$"Wta žUX]j]g]cb cZ5i h\]bl +bWtk UffUbhg h\]g dfcXi White VY ZYYY Zfca XYZYWfj Y a UhYf]U UbX k cf_a Ubg\]d Zcf UdYf]cX cZ%&\$ XUng Zfca h\Y cf][]bU XUhY cZdi fWtUgY UhfYhU]""L%\$ U[fYYg hc fYdU]f cf fYd UW žUh]hg gc Y X]gWfYh]cbž U XYZYWfj Y dfcXi Wh]Z fYh fbYX hc L%\$ k]h\]b h\Y k UffUbhmdYf]cX UbX k]h\ dfccZ cZdi fWtUgY" ≠ZgYfj]W]g fYei]fYX i bXYf h\]g k UffUbhm 7U "%, , , !' , (!\$- *- žj]g]hk k k" |%\$"Wta žcf Ya U] gi ddcfh4 | %\$"Wta