


CG 'STANDARD' GIRDER TURNING CLAMPS



The main purpose of the **CG girder turning clamps** are for the transportation and turning of steel girders (RSJ) through 90° degrees.

They can be used individually, or for longer beams used in pairs in conjunction with a spreader beam as shown in diagram.

The clamps are attached to the horizontal flange of the girder and locked in place by the jaw locking lever. Once lifted the girder will turn through 90° degrees.



Model	WLL kg*	Jaw capacity mm	Weight kg*
CG 1	100 - 1000	0 - 16	6
CG 2	200 - 2000	0 - 32	14