## Lifting365.... Base Emptying Stillage - Fully Automatic



A range of containers designed for most forklifts. These Base emptying stillages operate automatically when lowered against the side of a waste skip which allows the contents to be dumped without the driver leaving the seat

Supplied with legs as standard but can be fitted with castors if required (as per picture shown)

## Important Information

These units are not designed for wet loads as they will leak from the base, which can also cause overloading issues and possible damage to the locking mechanism

Model Ref	Volume Capacity	Load Capacity (kg)	Length (mm)	Width (mm)	Height (mm)	Weight (kg)
ADB 50	0.5m³	1000	1020	870	880	89
ADB 70	0.7m³	1000	1020	970	1040	139
ADB 100	1.0m³	1250	1320	1050	1040	165
ADB 150*	1.5m³	1500	1690	1050	1080	190
ADB 200*	2.0m³	1500	2000	1050	1080	228

## \* Castors fitted as standard

- Manufactured from 2mm thick steel side plates & 3mm thick base plate, for a long service life
- Fully automatic in operation, no wires or climbing required, offering fast & efficient operation
- Base automatically locks when lowered onto a solid surface, helps speed up operations
- Pallet feet fitted to underside of stillage to allow safe and convenient stacking
- Supplied with safety security chain to ensure the stillage is positively connected to the truck

