

Questions?
Click to Live Chat

NEED MORE HELP?

For all support go to jabra.com/support

Jabra Engage 65



Quick start guide



[Jabra.com/engage](https://jabra.com/engage)

81-04302 F

GN Making Life Sound Better




Connect to power



Plug the base into a power supply, and then press both volume buttons on the headset simultaneously to enter the voice-guided setup menu.


The voice-guided setup menu will help you connect to your computer or desk phone. For desk phones, connect all cables before following the voice guidance (refer to the following pages).

Desk phone cables



Desk phone without headset port




Connect the cables (as illustrated), and then follow the voice-guided menu to complete desk phone setup.



Desk phone with headset port



Connect the cables (as illustrated), and then follow the voice-guided menu to complete desk phone setup.

How to wear



The headset can be worn on the left or right ear.

How to use



Warning and Declarations

Corded and Wireless- North America

Please read through all applicable sections.

For your protection and comfort, GN Netcom, Inc. ("GN") has implemented protective measures in this product designed to maintain safe volume levels and ensure that the product operates in compliance with government safety standards.

AUDIO PRODUCT WARNING!

PERMANENT HEARING LOSS MAY RESULT FROM LONG-TERM EXPOSURE TO SOUNDS AT HIGH VOLUMES. USE AS LOW A VOLUME AS POSSIBLE.

This product might be capable of delivering sounds at loud volumes and high pitched tones.

Under certain circumstances, exposure to such sounds can result in permanent hearing loss damage. The volume level may vary based on conditions such as the phone you are using, its reception and volume settings, and the environment.

Avoid prolonged use of headsets at excessive sound pressure levels.

Please read the Safety Guidelines below prior to using this product.

You can reduce the risk of hearing damage by following these safety guidelines:

1. Prior to using this product follow these steps

- Before using the product, turn the volume control to its lowest level,
- Put the headset on, if applicable
- Slowly adjust the volume control to a comfortable level.

2. During the use of this product

- Keep the volume at the lowest level possible and avoid using the product in noisy environments where you may be inclined to turn up the volume;
- If increased volume is necessary, adjust the volume control slowly;
- Ringing in the ears may indicate that the sound levels are too high;
- If you experience discomfort or ringing in your ears, immediately discontinue using the product and consult a physician; and
- Stop using the product if it causes great discomfort.

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.



GENERAL SAFETY INFORMATION!

- Use of a headset will impair your ability to hear other sounds. Use caution when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy – never allow children to play with this product. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the product, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.
- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- If the product has ear tips, the ear tips should rest against, but not enter the ear canal.
- Keep all products, cords, and cables away from operating machinery.
- Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals, blasting areas, potentially explosive atmospheres, or aircrafts.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact GN Netcom, Inc.
- Never mount or store the product over any airbag deployment area, as serious injury may result when an airbag deploys.
- Do not use in areas where there are explosive hazards.
- Unplug the product during extreme weather, or when the product is not used for long periods of time.
- Protect the cords from being damaged or pinched.
- Dispose of the product according to local standards and regulations (see www.jabra.com/weee).

Remember: Always drive safely, avoid distractions and follow local laws!

The use of a speaker while operating a motor vehicle may be regulated by local laws. Using a headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some



jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check with your local authorities.

Use caution while using your product when you are engaging in any activity that requires your full attention. While engaging in any such activity turning off your product will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery

- Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
- The battery can be charged and discharged hundreds of times, but will eventually wear out. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- Unplug the charger from the electrical plug and the product when not in use.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the battery.
- Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A product with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Battery warning!

- "Caution" – The battery used in this product may present a risk of fire or chemical burn if mistreated. Batteries may explode if damaged.
- Only recharge your battery with the provided approved chargers designated for this product.
- Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste or in a fire as they may explode.
- Unless otherwise specified in the user manual or quick start guide the battery in your product can not be removed or replaced by the user. Any attempt to do so is risky and may result in damage of the product.
- Use of other batteries may present a risk of fire or explosion and the warranty will be terminated.

For information on batteries please go to www.jabra.com/batteries.

CHARGER CARE: Please observe the following if the product is supplied with a charger

- Do not attempt to charge/power your product with anything other than the charger provided. The use of any other types may damage or destroy the product and could be dangerous. Use of other chargers may invalidate any approval or warranty. For availability of approved enhancements, please check with your dealer.

- Charge/power the product according to the instructions supplied with the product.

Important: Please refer to the user manual for a description of the charging status indicator lights. Some products cannot be used while charging.

Charger warning!

- When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord. Never use a charger that is damaged.
- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock. Incorrect reassembly can cause electric shock or fire when the product is subsequently used.
- Avoid charging your product in extremely high or low temperatures and do not use the charger outdoors or in damp areas.

MAINTENANCE

- Unplug the product or charger before cleaning
- Clean the product by wiping with a dry or slightly damp cloth. The cord and charger may only be dry-dusted

DECLARATIONS

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Audio A/S is under license. Other trademarks and trade names are those of their respective owners. Wireless DECT standards vary depending on local legislation. Make sure that your product corresponds to the standard used in your country by ensuring that the product is purchased through a local source of distribution.

For warranty information, please go to www.jabra.com.

FCC and IFETEL (wireless equipment):

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by GN Netcom, Inc. will void the user's authority to operate the equipment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. Non body-worn devices must be placed at least 8" (20cm) away from the body.

FCC (corded equipment):

Limited One (1) Year Warranty

GN Netcom, Inc. ("GN") warrants to the first end-user purchasing the product from a distributor or reseller ("GN Partner"), that the product shall be free from defects in materials and workmanship subject to the terms set forth below ("Warranty") for a period of one (1) year from the date the product has been purchased ("Warranty Period").

If the product is sold or otherwise transferred to another party, the Warranty will automatically terminate prior to expiration. Furthermore, the Warranty will terminate immediately if the product is (a) altered, repaired, or maintained by anyone other than GN or a GN Partner which is authorized to do GN warranty work, whether or not successful, or (b) being used together with non-GN branded or certified accessories or other peripheral equipment.

During the Warranty Period, GN will, at GN's sole discretion (a) repair the product using new or refurbished parts, (b) replace the product with a new or refurbished product, or (c) refund the purchase price paid ("Warranty Service"). The Warranty sets forth the extent and limit of GN's obligations towards the end-user except as modified by applicable law.

Warranty on replaced or repaired products is twelve (12) months, OR the rest of the original Warranty Period, whatever is longest.

As part of GN's efforts to reduce environmental waste the product may consist of reconditioned equipment that contain used components, some of which may have been re-worked. The used components meet to GN's high quality standards and comply with GN's product performance and reliability specifications. Defective parts or products replaced by or returned to GN during the Warranty Period become the property of GN.

For more on how to obtain Warranty Service, please go to www.jabra.com.

Limitations of Warranty

This Warranty only applies to products purchased for use, not for resale. Specifically exempt from warranty are limited-life consumable components and accessories subject to normal wear and tear. For a complete overview of which consumable components and accessories that are not covered by this Warranty, please go to www.jabra.com.

This Warranty is invalid if the factory-applied serial number, date code label, and/or product label has been altered or removed from the product.

This Warranty only applies to defective factory material and factory workmanship and does not cover defects or damages caused by or attributable to (a) improper storage or faulty installation and operation; misuse or abuse; accident or neglect, (b) contact with any liquid, (d) use of the product or accessories for commercial purposes, or subjecting the product or accessories to improper or abnormal usage or conditions, or (d) other acts which are not the fault of GN, including matters attributable to a GN Partner.

This Warranty does not apply to products which have not been charged for six (6) months. If the battery in a product has not been charged for a period of six (6) months, the product might not function or regain its full potential and long-term performance. GN does not offer any warranty for such performance.

It is the end-user's responsibility to operate and care for the product in accordance with the instructions and specifications supplied with the product. Repairs resulting from failure to do so are not covered by the Warranty.

REPAIRS, REPLACEMENTS OR REFUNDING AS PROVIDED UNDER THIS WARRANTY ARE THE EXCLUSIVE REMEDY OF THE END-USER. NEITHER GN NOR YOUR GN PARTNER SHALL BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THE PRODUCT, INCLUDING WITHOUT LIMITATION COMMERCIAL LOSS, INCIDENTAL EXPENSES, LOSS OF TIME, OR INCONVENIENCE. EXCEPT TO THE EXTENT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PRACTICAL PURPOSE.

NOTE!

The Warranty gives the end-user specific legal rights. The end-user may also have other rights which vary from state to state or country to country. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or implied warranties, so the above exclusions may not apply. The Warranty does not affect statutory legal rights under applicable national or local laws.