

AC-32 USB TO RS232 ADAPTER CABLE



For use with computers that do not have a serial port connection

The computer device driver required to use this USB to RS232 adapter cable comes installed on most computers. If needed, the latest version of the device driver can be downloaded free at www.ftdichip.com. Please follow the instructions on the website to download the device driver. The driver type you want to choose is the Virtual COM Port (VCP).



Auto Meter Products Inc.

413 West Elm Street Sycamore, IL 60178

Service (815) 899-0801 Toll Free (866)-883-TEST (8378)

www.autometer.com/test

2650-1562-00 3-

3-7-2011

GLASSE



For use with computers that do not have a serial port connection

The computer device driver required to use this USB to RS232 adapter cable comes installed on most computers. If needed, the latest version of the device driver can be downloaded free at www.ftdichip.com. Please follow the instructions on the website to download the device driver. The driver type you want to choose is the Virtual COM Port (VCP).



Auto Meter Products Inc.

413 West Elm Street Sycamore, IL 60178

Service (815) 899-0801 Toll Free (866)-883-TEST (8378)

www.autometer.com/test