ASSEMBLY INSTRUCTION MODEL: 459DB/QB

ead this instruction carefully. Remove all wrapping material, staples and straps from the carton. ee hardware and furniture part list for guidance. Be sure you have all wooden furniture parts on a lean and flat soft surface, such as a carpet or rug, to prevent from being scratched. Follow the

igure to start assembling.

AUTION:

- . Do not FULLY TIGHTEN the nut or crew untill all is ready to assemble.
- . Do not OVER TIGHTEN the nut or crew to avoid causing damages to he thread.
- 3. Keep all hardware part out reach of children.

NO	PART LIST	QTY	
А	HEAD BOARD	1 PC	
В	FOOT BOARD	1 PC	
С	SIDE RAIL	2 PCS	
D	CENTER LEG SUPPORT	4 PCS	
Е	HEAD BOARD LEG	2 PCS	
F	FOOT BOARD LEG	2 PCS	
G	FLAT SLAT	4 PCS	
Н	CENTER SUPPORT RAIL	1 PC	

			,
NO	DESCRIPTION		QTY
1	JCBC SCREW M6 x 45MM	0	4 PCS
2	SPRING WASHER M6	0	4 PCS
3	CSK SCREW M4 x 30MM	Time	12 PCS
4	M4 ALLEN KEY		1 PC
5	M5 ALLEN KEY	<u></u>	1 PC
6	JCBC SCREW M6 x 70MM	3	2 PCS
7	CSK SCREW M4 x 45MM	Jumin .	2 PCS

