

Remove towel warmer from the wall.

Flip the towel warmers upside down so that the element is at the top.




Switch element and cap positions.





4

Unscrew element with adjustable wrench and unscrew the cap cover with an allen wrench.



artos