


Assembly Instructions




ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)

EASY




DIFFICULT


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




1
When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2
Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3
Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4
Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5
Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6
Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List



#1 x 1pc x 2
Backrest W/Legs



#2 x 1pc x 2
Seat



#3 x 1pc x 2
Seat Frame



#4 x 2pcs x 2
Leg



#5R x 1pc x 2
Right Stretcher Support



#5L x 1pc x 2
Left Stretcher Support



#D x 1pc
Allen wrench

Hardware List




#A x 10pcs x 2
Bolt 1/4"X 1/2"



#B x 2pcs x 2
Bolt 1/4"X 5/8"



#C x 4pcs x 2
Screw



x 2




#1

#A x 4pcs

1. Place the backrest w/legs (#1) onto a protected surface.

2. Align both ends of the seat frame (#3) to the pre-drilled holes along the front of the backrest w/legs (#1).



3. Insert 2 bolts (#A) into each end of the seat frame (#3) and secure using the Allen wrench.




#2

#A x 4pcs

1. Align the legs (#4) to the front of the seat frame (#3).

2. Insert 2 bolts (#A) into each leg (#4) and secure using the Allen wrench.






#3

#A x 2pcs
#B x 2pcs

1. Align the right stretcher support (#5R) to the right side of the backrest (#1) and seat frame (#3).

3. Insert a bolt (#B) into the hole connecting to the seat backrest with legs (#1) and secure using the Allen wrench.

4. Repeat the process for the left stretcher support (#5L).



2. Insert a bolt (#A) into the hole connecting to the seat frame (#3) and secure using the Allen wrench.




#4

#C x 4pcs

1. Place the seat (#2) onto the seat frame (#3).

2. Insert 4 screws (#C) from below and secure.



ASSEMBLY IS COMPLETED