
#### **TOOLS REQUIRED**



#### Allen Wrench

(Included)



#### Phillips Screwdriver

(Not Included)



2 - People Recommended

#### **ASSEMBLY RATING**



EASY --- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

**VERSION # 22-02-16** 



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?  Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

# Kitchen Island



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



#### **PARTS**





#2)1pc









Left Leg



**Top Panel** 

1pc

Top Frame

Frame

Frame #8)1pc

Right Leg







1pc



Side panel

**Bottom Panel** 

Wood Top Frame

Back Supporting Leg

















Front Supporting Leg

Stretcher

**Back Panel** 

Horizontal Panel

#16) 2pcs

(#13) 2pcs



1pc





Vertical Panel




Adjustable Shelf

**CUP-Hanging** Wood

**CUP-Hanging** 

Wood


#### **HARDWARE**




Carton	Disignation		Part	Hardware	
	Top Panel	#1			
	Left Leg Frame	#3			
	Right Leg Frame	#4			
	Back Supporting Leg	#8			
	Front Supporting Leg	#9			
	Stretcher	#10	•••		
	OUD II	#15	[o o]		
	CUP-Hanging Wood	#16	(o o)		
	Top Frame	#2			
	Side panel	#5	H	(0))2022222222	#A 11pcs
	Bottom Panel	#6		0	#B 11pcs #C 11pcs
	Wood Top Frame	#7			#D 2pcs
	Back Panel	#11			#E 1pc #F 23pcs
	Horizontal Panel	#12		0	#G 23pcs
	Vertical Panel	#13			#H 23pcs #K 1pc
	Adjustable Shelf	#14			

Pull out all drawers on the top frame(#2).


1





3 Part (#3) 1pc Hardware #A 3pcs Hardware #B 3pcs Hardware #C 3pcs 4 Part #15 2pcs

Align and secure left leg frame (#3) to the top frame (#2) using bolts (#A) with washers (#B, C).




Part #16 2pcs

Hardware (#F) 8pcs

Hardware #G 8pcs

Hardware (#H) 8pcs



5


Part #5 1pc

Hardware #F 3pcs

Hardware #G 3pcs

Hardware #H 3pcs

Align side panel (#5) to the top frame (#2), then secure using bolts (#F) with washers (G,H).



6


Part (#4) 1pc

Hardware #A 3pcs

Hardware #B 3pcs

Hardware (#C) 3pcs

Attach right leg frame (#4) to the top frame (#2) by using bolts (#A) with washers (#B,C).



7 Part #6 1pc

Hardware #A 3pcs

Hardware #B 3pcs


Hardware #C 3pcs

Hardware (#F) 3pcs

Hardware #G 3pcs

Hardware #H 3pcs

1. Align bottom panel (#6) to leg frames (#3,4), then secure using bolts (#A) with washers (B,C).



8


Part #8 1pc

Part (#9) 1pc

Part #10 1pc

Hardware #D 2pcs

Align and secure stretcher (#10) to the front and back supporting legs (#8,9) by using screw (#D).



9


Part (#7) 1pc

Hardware #A 2pcs

Hardware #B 2pcs

Hardware #C 2pcs

Secure legs (#8,9) to the wood top frame (#7) using bolts (#A) with washers (#B,C).




10

Hardware #F 1pc

Hardware #G 1pc

Hardware #H 1pc

Insert assembly and attach center of stretcher (#10) to the rail on bottom panel (#6). Secure with bolt (#F) and washer (#G,H).




### 11

#### Insert panels (#13) to panel (#12).


Part #11 1pc
Part #12 1pc

Part #13 2pcs



12

Part #14) 2pcs



# ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.


✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

13





#### ✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.