

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



4 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION #23-03-28



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


BUNK BED






PARTS





Exploded View



packed in 2 cases

Carton	Disignation	Part		Hardware	
	Top Side Panel (R)	#1			
	Top Side Panel (L)	#2			
	Bottom Side Panel	#3			
	Front Side Rails	#4	(20 ca co co ca		#A x 16pcs
	Back Side Panel	#5	(20 00 00 00 00 00)	_	#B x 6pcs #C x 6pcs
	Back Guardaril Bars	#6			#D x 6pcs #Ex 30pcs
	Font Guardaril Bars	#7			#F x 4pcs
	Slats	#8		2	#G x 1pcs #H x 16pcs
	Guardaril Reinforce Bars	#9			
	Ladder (Left)	#10			
	Ladder (Right)	#11			
	Ladder Steps	#12			

Align bottom side panels (#3) to the side rails (#4,5), then secure by using bolts (#A) onto moons (#H).


Part #3 x2pcs


Part #4 x1pc

Part #5 x1pc

Hardware (#A) x8pcs

Hardware #H x8pcs





Insert dowels (#F) to the top of the bunk bed as shown in the diagram.

3

Part #1 x1pc

Part #2 x1pc

Part #4 x1pc

Part #5 x1pc


Part #6 x2pcs

Hardware (#A) x8pcs

Hardware #D x4pcs

Hardware #H x8pcs

Align side rails (#4,5) to the top side panels (#1,2), then secure by using bolts (#A) onto moons (#H).



4

Part #10 x1pc

Part #11 x1pc

Part #12 x3pcs

Hardware #C x6pcs

ladder rails (#10,11), then secure by using screws (#C).


#10


#G


#12


Align ladder steps (#12) to the

5










10



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

Safety Warnings for Bunk Beds

- Read and follow the information on the WARNINGS shown on the end structure of the upper bunk and on the carton.
- Do not remove warning label from the bed.
- Keep these instructions for future reference.
- 4. IMPORTANT: Must use Bunkie mattress or Bunkie board. The proper sizes for the UPPER/LOWER TWIN-SIZE Bunkie mattress or Bunkie board should be 74" long and 37½" - 38½" wide with no more than 6" thickness and for the UPPER/LOWER FULL-SIZE should be 74" long and 53" - 54" wide with no more than 6" thickness.
- Surface of mattress must be at least 5 inches (127 mm) BELOW the upper edge of guardrails.
- 6. The MAXIMUM weight capacity for the upper bunk is not to exceed 175 lbs.
- Do not allow children under 6 years of age to use the upper bunk.
- Periodically check and ensure that the guardrails, ladder, handle and other components are in their proper position, free from damage, and that all connectors are tightened and secured.
- DO NOT allow horseplay, rough playing or jumping on the beds and do not allow playing or hiding under the beds.
- 10. Always use the ladder for entering or leaving the upper bunk.
- Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- Use of a nightlight may provide added safety precaution for a person using the upper bunk.
- Always use the guardrails on both sides of the upper bunk.
- 14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.
- 15. The use of water or sleep flotation mattresses is prohibited.
- 16. No more than one person is allowed on the upper bunk at all times.



WARNING: STRANGULATION HAZARD

Never attach or hang objects to any part of the bunk bed that are not designed for use with the bed. Objects such as hanger, hook, belt, bag, rope, string, etc. should not be used on or around the bunk bed.