

SINTUNG Spare Parts

Part	Description
16377 A	Ratchet Pivot, Washer & Nut
16377 B	Central Bolt and nut
16377 C	Cutting Blade
16377 D	Short Spring
16377 E	Main Spring
16377 G	Central Spring
16377 L	Plastic Click
16377 J1	12mm Bearing
16377 P2	Ratchet Plate
16377 W3	7mm Metal Spacer

