

Gate Stop and/or Padlock Eyes Installation

(1300-00SP/ 1300-00SC AND 1400-BSS/ 1400-WSS/ 1400-SSS on wood gates)

INSTALLING GATE STOP



Our stainless steel gate stop (Part # 1400-BSS) is ideal and recommended.

Close the gate with horizontal bar on the latch just touching the catch on the fence post. With the gate in this position install stop block on latch

post. Ensure the front of the block fits snug against the gate in this closed position.

The use of a stop block on the latch post is recommended when using a gate spring, cannonball gate closer, or in cases where the gate is subject to high winds. Failure to install a stop block voids warranty.



INSTALLING PADLOCK EYES



Optional padlock eyes (Part # 1300-00SP) can be installed if the gate needs to be locked. Install one eye on the inside of the latch post and the other eye on the edge of the gate (using screws provided) ensuring that the eyes align with each other). Ideally the padlock eyes should be installed just below the ring latch as shown in the picture at left. Lock gate with suitable padlock (not included).

SNUG COTTAGE HARDWARE

London, Ontario, Canada and Marysville, Michigan, USA

Phone (519) 473-2794 Fax (519) 474-3337

www.snugcottagehardware.com

Printed in the U.S.A.