

DIGITAL WATCH

Thank you for choosing a Tikkers watch! This short guide will help you with the essentials, but please visit our website to access full instructions, helpful videos, FAQs and more, all designed to help you get the best from your Tikkers products.



The normal display shows hour, minute, seconds, day and month.

- 2. 12/24 Hour Format selectable
- 3. Calendar
- 4. Daily Alarm and Chime function;
- 5. Stop watch function
- 6. EL backlight

FUNCTION MODE

In normal display press button "B" to switch between different function modes. Press once for stopwatch press twice for alarm and press three times to amend time and date.

TIME SETTING MODE

In normal display, press button "B" three times to enter time setting mode, 'seconds' starts to flash. Press button "D" to select in sequence as shown below. Seconds - hours - minutes - month - date - day - seconds Press button "C" to adjust adjust selected digits. -12hr format A =AM/P=PM. -24hr format = H visible when amending hour. Press button "B" to accept the change.

ALARM SETTING MODE

In normal display, press button "B" twice to enter Alarm setting mode. Press button "D" to start amending the time. Pressing button "C" will increase the selections- hour and minutes. Press button "D" to move from hour to minutes. Press button "B" or "D" to accept change & return to show normal time. Alarm will repeat if no buttons are pressed when the alarm rings, this will repeat every 5 minutes for 5 times. Press button "D" to switch on and off alarm and hourly chime when symbols are visible on the screen this means they are switched on.

STOP WATCH MODE

In normal display, press button "B" to enter Stopwatch mode. Button "C" will start and stop stopwatch. Button "D" will reset stopwatch. Whilst the stopwatch is working, pressing button "C" will create a split time to review. By pressing button "C" again you can resume the timer.

TIKKERS.CO.UK

HOW TO CARE FOR YOUR WATCH

Batteries should only be replaced by a qualified technician, please don't try to open the caseback yourself. Do not wear your watch whilst applying sprays or creams. Do not allow contact with any corrosive agents such as paint, solvents or adhesives as these may affect the case and finish. Do not immerse your watch in water.

1KKER3

GUARANTEE

Your TIKKERS[™] watch is guaranteed against defects of material and manufacture for 12 months from date of purchase. There are a few things not covered by the guarantee:

- Batteries, straps or bracelets
- Damage caused from accidents or mishandling
- Water penetration

This guarantee does not affect your statutory rights. We are confident you'll love your new watch, but if you do have any issues under the terms of the guarantee, then please contact the Tikkers™ Team who will be happy to help. You can contact us Monday to Friday, 9AM to 4PM on:



Tikkers products are manufactured by Peers Hardy: UK - Peers Hardy UK Itd, Precision House, Starley Way, Birmingham Business Park, Bickenhill Lane, Solihull, B37 76N.

EU - Peers Hardy UK UTD, C/O Global E-com Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.

DISPOSAL OF GOODS

The crossed out wheelie bin symbol is to remind you that waste electrical products, batteries and accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility.

• Do not dispose of your TIKKERS product within household waste.

• Disposal of your TIKKERS packaging and product should be done in accordance with local regulations.

CONTACT US

If you require any further assistance using your TIKKERS Watch we are here to help!

You can also contact our friendly, UK based customer service team Monday to Friday, 9AM to 4PM on:

+44 (0) 121 524 1400

There is also lots of information on our website tikkers.co.uk that you may find helpful.

NEED SUPPORT?



TIKKERS.CO.UK

Don't forget to follow us on social media for lots of fun stuff! We'd love you to tag us in your photos showing your new TIKKERS™ products!

FOLLOW US ON SOCIAL MEDIA!

存 Tikkers.Official 🧿 Tikkers.Official

とう くち 🕱

