


fresco chrome

ages & stages

stage 1 cradle



stage 2 high chair



do not forget to remove the booster and switch back to the large seat pad as soon as your infant is tall enough (or at 18 months)

stage 3 kids chair

